



**EL212F
Industrial Ethernet
Managed Switch**

Installation Guide

Revision: 16 January 2014

www.redlion.net

This page intentionally left blank.

Installation Guide

Industrial Ethernet Switch

Layer 2 with 8 + 4G:

- *8 100BASE-BX (SFP) Ports*
- *2 1000BASE-T (SFP) Ports*
- *2 Combination Gigabit (RJ45/SFP) Ports*

About This Guide

Purpose

This guide gives specific information on how to properly install and maintain the switch.

Audience

The guide is intended for use by network administrators who are responsible for installing and setting up network equipment; consequently, it assumes a basic working knowledge of electrical safety and any local, regulatory or corporate rules for the installation of industrial electrical equipment.

Conventions

The following conventions are used throughout this guide to show information:

Note or Notice: Emphasizes important information or calls your attention to related features or instructions.

Caution, risk of danger: Alerts you to a potential hazard that could cause loss of data, or damage the system or equipment. Documentation must be consulted in all cases where this symbol is marked.



Typical caution symbol.

Warning, risk of electrical shock: Alerts you to a potential hazard that could cause personal injury.



Typical warning symbol.

Related Publications

The following publication details the software features of the switch, including the Web interface, CLI and much more:

EL Series Management Guide

Also, as part of the switch's software, there is an online web-based help that describes all management related features.

Revision History

First release.

Copyright & Trademarks

Copyright ©2014 Sixnet Inc. All Rights Reserved.

Note: All information in this document is subject to change without notice.

Compliance and Safety Information

Installation Warnings



Please read the following safety information carefully before installing or performing any maintenance on the switch. This equipment is suitable for use in Class I, Division 2, Groups A, B, C, D or non-hazardous locations only.

Note: Only the EL212F-DC-VI is approved for Zone 2 (ATEX) areas.

Warning: These products should not be used to replace proper safety interlocking. No software-based device (or any other solid-state device) should ever be designed to be responsible for the maintenance of consequential equipment or personnel safety. In particular, Red Lion disclaims any responsibility for damages, either direct or consequential, that result from the use of this equipment in any application. All power, input and output (I/O) wiring must be in accordance with Class I, Division 2 wiring methods and/or in accordance with the authority having jurisdiction. Refer to section 1 for other important installation warnings.

- **Warning:** Installation, maintenance and removal of the switch must be carried out by qualified personnel only.
- **Warning:** Install the Managed Switches in accordance with local and national electrical codes.
- **Warning:** The unit must be properly grounded to comply with international standards.
- **Warning:** If equipment is used in a manner not specified by the manufacturer, the protection provided by the equipment may be impaired.
- **Warning:** Do not connect to an AC power supply without an earth ground.
- **Warning:** This product does not contain any user serviceable parts.
- **Warning:** Do not work on equipment during periods of lightning activity.
- **Warning:** Do not connect a telephone line into one of the Ethernet RJ45 connectors.
- **Warning (explosion hazard):** Substitution of components may impair suitability for Class I, Division 2 (Zone 2) areas.
- **Warning (explosion hazard):** When in hazardous locations, disconnect power before servicing units.
- **Warning (explosion hazard):** Do not disconnect equipment unless power has been switched off or area is known to be nonhazardous.
- **Warning (explosion hazard):** In hazardous or potentially hazardous locations, do not separate any part of unit when energized. Use the unit for internal connections only.
- **Warning (explosion hazard):** No hot swapping of modules in Hazardous Locations.

CAUTIONS POUR INSTALLATION



S'il vous plaît lire attentivement les consignes de sécurité suivantes avant d'installer ou d'effectuer un entretien sur l'appareil. Cet appareil est adapté pour utilisation de Classe I, Division 2, Groupes A, B, C, D ou endroits non-dangereux.

Note: Seul EL212F-DC-VI est approuvé pour les endroits Zone 2 (ATEX).

Avertissement : Ces produits ne doivent pas être utilisés pour remplacer le verrouillage de sécurité approprié. Aucun dispositif basé sur un logiciel (ou tout autre dispositif à l'état solide) devraient jamais être conçus pour être responsable de l'entretien de l'équipement consécutifs ou la sécurité du personnel. En particulier, Red Lion décline toute responsabilité pour les dommages, directs ou indirects, résultant de l'utilisation de cet équipement dans n'importe quelle application. Tout courant, câblage entrée et sortie (I / O) doit être conforme aux méthodes de câblage à la Classe I, Division 2 et conformément à l'autorité compétente. Référer à la section 1 pour les autres avertissements d'installation importantes.

- **Avertissement:** Installation, entretien et l'enlèvement de l'interrupteur doivent être effectués par du personnel qualifié.
- **Avertissement:** Installez les Commutateurs Gérés conformément aux codes électriques locaux et nationaux.
- **Avertissement:** L'appareil doit être correctement mis à la terre afin de se conformer aux normes internationales.
- **Avertissement:** Si l'équipement est utilisé d'une manière non spécifiée par le fabricant, la protection fournie par l'équipement peut être altérée.
- **Avertissement:** Ne pas se connecter à une source d'alimentation CA sans une prise de terre.
- **Avertissement:** Ce produit ne contient pas de pièces réparables par l'utilisateur.
- **Avertissement:** Ne pas travailler sur le matériel pendant les périodes d'activités de la foudre.
- **Avertissement:** Ne branchez pas une ligne téléphonique dans l'un des connecteurs RJ45 Ethernet.
- **Avertissement (risque d'explosion):** La substitution de tout composant peut nuire à la conformité de Classe I, Division 2 (Zone 2).
- **Avertissement (risque d'explosion):** Lorsque dans des endroits dangereux, débranchez le cordon d'alimentation avant de remplacer ou de brancher des modules.
- **Avertissement (risque d'explosion):** Ne débranchez pas l'équipement pendant que le circuit est direct ou à moins que l'environnement soit connu pour être libre de concentrations inflammables.
- **Avertissement (risque d'explosion):** Dans les endroits dangereux ou potentiellement dangereux, ne pas séparer une partie de l'unité sous tension. Seulement utilisez l'appareil pour les connexions internes.
- **Avertissement (risque d'explosion):** Pas de remplacement à chaud des modules dans les zones dangereuses.

Fiber Optic Safety



Warning: When using fiber optic ports, never look at the transmit laser, fiber TX port or fiber cable ends while the switch is powered on. It is highly recommended to keep the rubber fiber plugs inserted when the fiber port is not being used.

Hi-Pot (Dielectric) Testing



Caution: This device is designed to withstand a high-potential “hi-pot” (dielectric) test up to 2000 VAC or 2800 VDC (1 minute), or 2400 VAC or 3300 VDC (1 second) according to IEEE 1613. However, the surge circuitry must be bypassed before performing this test. See section 8 for details.

	Power Markings
	 Direct Current (DC)
	 Alternating Current
	 Protective Conductor Terminal

FCC Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- This device may not cause harmful interference.
- This device must accept any interference received, including interference that may cause undesired operation.

Warning: This equipment has been tested and found to comply with the limits for digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Notice: Shielded interface cable must be used in order to comply with emission limits.

Notice: Changes or modification not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Industry Canada Statement

This device complies with the limits of Industry Canada per ICES-003. Operation is subject to the following two conditions:

- This device may not cause harmful interference, and
- This device must accept any interference received, including interference that may cause undesired operation.
- Ce dispositif peut ne pas causer l'interférence nocive, et
- Ce dispositif doit accepter n'importe quelle interférence reçue, y compris l'interférence qui peut causer l'opération peu désirée.

Warranty Statement

Red Lion, manufacturer of Red Lion products, warrants to Buyer that products, except software, manufactured by Red Lion will be free from defects in material and workmanship. Red Lion's obligation under this warranty will be limited to repairing or replacing, at Red Lion's option, the defective parts within five (5) years of the date of installation, or within 60 months of the date of shipment from the point of manufacture, whichever is sooner. Products may be returned by Buyer only after permission has been obtained from Red Lion. Buyer will prepay all freight charges to return any products to the repair facility designated by Red Lion.

This limited warranty does not cover losses or damages which occur in shipment to or from Buyer or due to improper installation, maintenance, misuse, neglect or any cause other than ordinary commercial or industrial applications. In particular, Red Lion makes no warranties whatsoever with respect to implied warranties of merchantability or fitness for any particular purpose. All such warranties are hereby expressly disclaimed. No oral or written information or advice given by Red Lion or Red Lion's representative shall create a warranty or in any way increase the scope of this warranty.

This limited warranty is in lieu of all other warranties whether oral or written, expressed or implied. Red Lion's liability shall not exceed the price of the individual units, which are the basis of the claim. In no event shall Red Lion be liable for any loss of profits, loss of use of facilities or equipment, or other indirect, incidental or consequential damages.

Note: The EL212F switches have no user serviceable parts. Any unauthorized service will void all warranties. In the unfortunate event that service is required please contact Red Lion for further instructions.

Getting Support

For local support please contact your regional Red Lion office. Otherwise, to get product information or contact Red Lion directly:

- **Latest product info:** <http://www.redlion.net>
- **E-mail:** support@redlion.net
- **Phone:** 1-877-432-9908
- **Fax:** 1 -518-877-8346
- **Mailing address:** Red Lion Controls, 20 Willow Springs Circle, York, PA 17406, USA

Products Covered

This manual applies to the following products:

- **EL212F** 12-port managed industrial Ethernet rack-mount switch

Contents

Section 1	General Information	Page 11
Section 2	Installation and Mounting	Page 13
Section 3	Thermal Considerations	Page 15
Section 4	Power and Output Wiring	Page 16
Section 5	Communication Wiring	Page 19
Section 6	LED Indicators	Page 23
Section 7	Reset Button	Page 24
Section 8	Technical Specifications	Page 25
Section 9	Service Information	Page 27

Section 1

General Information

Overview

The Red Lion EL212 is a 12 port (8 + 4G) industrial Ethernet managed switch designed to meet the extreme requirements of power substations, traffic control, railway and other harsh environments. It combines the high performance and security of an enterprise-class switch with rugged packaging and protected circuitry to meet the needs of the most demanding applications.

This manual will help you install and maintain these industrial Ethernet switches. Installation of these switches is very easy and they will begin to operate as soon as they are powered up. Though these are fully managed switches, they will act as unmanaged until they are configured otherwise. Refer to the separate software manual or management guide for configuration of the advanced networking functionality and security.

Note: This manual only covers the installation and wiring of these switches. Refer to the separate **Management Guide** for details on configuring and using any of the management functions such as **SNMP, RSTP, IGMP, VLANs, security, port mirroring and much more.**

Basic Operation

Unlike an Ethernet hub that broadcasts all messages out all ports, these industrial Ethernet switches will intelligently route Ethernet messages only out the appropriate port. The major benefits of this are increased bandwidth and speed, reduction or elimination of message collisions, and deterministic performance when tied with real-time systems.

These industrial Ethernet switches support 10BaseT (10 Mbps), 100BaseT (100 Mbps) and 100BaseF (100 Mbps) fiber connections on the first 18 ports. This is accomplished by way of pluggable SFP transceivers. The 4 Gigabit ports supports 10/100/1000BaseT (10/100/1000 Mbps) on their RJ45 ports plus 100/1000BaseF (100/1000 mbps fiber) via the two available SFP cages. All of the copper RJ45 ports will independently auto-sense the speed/duplex and mdi/mdix-crossover allowing you to use straight or crossed-wired cables. Fiber optic transceivers are available to make noise-immune multimode and singlemode connections up to 120 km.

General Specifications

These general specifications apply to these industrial Ethernet switches. Refer to Section 7 for complete technical specifications.

Number of ports	12 Ethernet ports
Ethernet Switch Type	Managed
Ethernet Switch Mode	Store and forward, wire-speed, non-blocking
Ethernet Protocols	All standard IEEE 802.3 protocols supported
Ports 1 through 8	SFP for pluggable transceivers of type 10/100 Mbps copper RJ45 or 100 Mbps fiber optic
Ports 9 and 10	Gigabit combination ports with both RJ45 (10/100/1000) and SFP slots for 100 or 1000 Mbps fiber transceivers
Ports 11 and 12	Gigabit SFP ports for 10/100/1000 Mbps connections
RJ45 Ports Operation	Auto-negotiation, auto-mdi/mdix-crossover and auto-polarity
Fiber Optic Type	Multimode, singlemode, long-haul or special application
Package style	DIN Rail Mounted

Compliances



These industrial Ethernet Switches meet the following standards plus others:

Sixnet Inc. is an ISO9001:2008 certified company (FM 65232) since 1996. These devices are designed, developed and manufactured per an ISO9001 quality management system.

Electrical safety

These devices have been designed to meet the basic safety requirements of the following standards:

- CE per Low Voltage Directive and EN/IEC 61010-1
- UL508 (Industrial control equipment) ANSI / ISA12.12.01 (Hazardous Locations)
- CSA C22.2 No. 142 and No. 213 (per cUL)
- Zone 2 (ATEX), Only EL212F-DC-V1 is approved for Zone 2 (ATEX) areas.

EMC (emissions and immunity)

- CE per the EMC directive
- IEC 61000-6-2: Immunity in industrial environments
- IEC 61000-6-4: Emissions in industrial environments
- FCC part 15 and ICES 003;. See FCC statement on page 7.
- EN 55022 (CISPR22)
- IEC 61850: EMC immunity, mechanical and climatic conditions in power substations
- IEC/TS 61000-6-5: EMC immunity in power substation environments
- IEEE 1613: EMC and climatic conditions in power substations

WEEE compliance

These devices comply with the WEEE directive. Do not throw away these devices in the standard trash. Contact Red Lion regarding proper disposal.

RoHS compliance

These devices comply with the RoHS directive and are considered lead and other hazardous substance free.


Section 2

Installation and Mounting


Overview

Important Note: Make sure to read Section 3 regarding thermal considerations before installing your switch.

Important Note: When you are choosing your mounting option make sure to allow enough room to route your Ethernet copper or fiber optic cables. Also, please consult the specifications for your fiber optic cable to make sure you allow for the proper bend radius.



Note: AutoCAD and other drawings are available on the CD or at: www.redlion.net



Mechanical Dimensions for the EL212

Section 3

Thermal Considerations

Overview

The EL212 switches are designed to operate from -40 to +85°C when they are installed properly. The switch is cooled via conduction and radiation. There are no fans. Instead there are various heat-sinks inside and outside the switch to conduct the heat from the components to the heavy-gauge aluminum case. The heat is then dissipated from the case via radiation to the surrounding air.

Note: An air gap is not absolutely necessary but highly recommended when you know that the switch will experience high heat (> 60°C) for extended periods of time.

BTU / Hour

The power consumption of the switch can be as much as 45 Watts with all ports linked and active. Based on this, the heat dissipation can be as much as 154 BTU per hour. Please plan your system accordingly.

Section 4

Power and Output Wiring



Power Overview

Warning: Please read this section fully before connecting your power input or alarm output! The unit must be powered down and the power plug removed before any wiring is done to the power plug. Otherwise, there is a risk of electrical shock if the rules and warnings in this manual are not properly adhered to.

The EL212 switches are offered with several power options including dual power supplies that can keep the switch running when there is a power input failure or internal power supply failure.

Standard Power Supply Options:

Option A0 = single 100/240 (50/60 Hz) VAC power or 110/250 VDC power – P1 accepts 85-264 VAC or 90 to 300 VDC (min/max)

Option D0 = single +/-24/48VDC (Class 2 Source) power inputs – P1 accepts +/-18 to 59 VDC (min/max)

Note:

With the dual options the two power supplies are completely isolated so each input/supply can be connected to a different voltage as long as it is in the range for that supply.

Special Order Options:

Other power input options may be available. Contact Red Lion for details.

Caution: Make sure that you know what type of power your switch accepts and make sure that your input power is within the ranges as defined above. Otherwise, you may damage your switch by applying the wrong power.

For the highest electrical safety the EL212F switches are provided with several grounding points. First, there are two green ground screws (see images) that attach directly to the switch case. They are supplied pre-installed on one side of the switch but they can be moved to the other side as desired. These screws can be used to provide a NEBS compliant safety ground. Please follow all the NEBS grounding rules and your own local requirements (which are not documented in this manual) to ensure the safe operation of the switch. Alternatively, the power plug has a chassis ground terminal (#4) that can be used to safety ground the switch. This terminal is internally tied to the switch case. In addition, there is a ground terminal for each power input. Use these to terminate the ground wire for each of your power inputs.


Note: The 2 Safety Guard Screws are designed to be used with Ring Lug Terminals. Do not wrap ground wire around either of the safety ground screws.

Warning: It is recommended that you make your safety ground connections first before connecting any power to the switch. Make sure that all power is off before making any power or ground connections to the switch.



Safety Grounding

Two #10-32 Screws for NEBS Compliant Safety Grounding



Power Labeling

The power headers and plugs will be labeled to guide you in properly connecting your power. Make sure to reference this labeling when wiring your switch to make sure you are connecting the appropriate power to the correct terminals. If your switch does not have dual power inputs then do not connect anything to the terminals labeled Power 2.




Power Header and Plug Labeling



Power Plug Installed

Power Wiring for EL212 Switches



AC Power Systems

For AC powered systems the terminals will be labeled as “+L” for Line (aka Hot), “-N” for Neutral and the chassis ground symbol for ground. Connect your AC power input as correspondingly. Typically the Line (Hot) lead is colored black or brown, the Neutral lead is colored white or blue and the ground is green or green/yellow.

Positive (+) DC Power Systems

For positive power systems (such as +24 VDC) put the positive lead on the terminal marked “+L” and the return (or ground) lead on the terminal marked “-N”. If there is a chassis, earth or safety ground lead then put it on the associated terminal marked with the chassis ground symbol.

Negative (-) DC Power Systems

Both the power option “A” and “D” support negative power systems. If your power is negative (such as -48 VDC) then you must put the most positive lead on the “+L” terminal. Always use a voltmeter to verify which lead is more positive. Then put the more negative lead on the “-N” terminal. If there is a chassis, earth or safety ground lead then put it on the associated terminal marked with the chassis ground symbol.

Reverse Polarity Protection

The “D” option power inputs are reverse polarity protected. This means that if you swap the + and – leads then the switch will not be damaged. However, the switch will not operate when wired this way.

“OK” Alarm Output

The switches have an “OK” alarm output that can be tied to a PLC input, an alarm indicator (visible or audible) or other device to indicate when there is an alarm condition (such as the loss of a power input). The alarm output is a Form C relay with a normally open (NO), normally closed (NC) and common (C) screw terminal. Apply an appropriate power source to the common (C) terminal.

Alarm Output Ratings:

Maximum voltage = 250 VAC or 30 VDC


Maximum current = 2 A @ 30 VDC or 250 VAC

Minimum load = 10 mVDC, 10 μ A

The relay will operate as follows:

Condition	NO Contact	NC Contact
No power to switch	Closed (shorted to common)	Open
Switch powered with no alarms	Open	Closed (shorted to common)
Switch powered with an alarm	Closed (shorted to common)	Open

Alarm Wiring for EL212 Switches



Wire Gauge & Screw Torque

The screw terminals are removable and secured by two screws. They will accept wire in the range of 24 to 14 AWG. When tightening the screws be careful to tighten to a maximum torque of 4.5 in/lb (0.51 Nm). We recommend a minimum of 18 AWG for the input power wires.

Section 5


Communication Ports Wiring

Overview

Gig RJ45 Ports 9 & 10

The EL212 switches provide connections to standard Ethernet devices such as PLCs, Ethernet I/O, industrial computers and much more. Three types of communication ports may be found on these switches: RJ45 (copper) Ethernet ports, SFP (pluggable) Ethernet ports and console (serial RS232) ports.

The EL212 has Gigabit RJ45 copper ports (9 and 10) that accept 10/100/1000 Mbps twisted pair cabling. Use data-quality (not voice-quality) twisted pair cable rated category 5E (or better) with standard RJ45 connectors. Straight through or crossover RJ45 cable can be used regardless of the device the switch is to be connected to as all the ports are capable of auto-mdi/mdix-crossover detection.




The RJ45 Ethernet port connector bodies on these products are metallic and are connected to the Chassis GND terminal. Therefore, shielded cables should be used to provide further protection from electrical noise and interference. Ideally, to prevent ground loops, the cable shield should be tied to the metal connector body at one end of the cable only. Electrical isolation is also provided on the Ethernet ports for increased reliability.

Note: The use of shielded cables is required to fully meet the requirements of IEC 61850 and IEEE 1613 standards.

For Reference Only.
Either cable wiring will work!

Straight-thru Cable Wiring	
Pin 1	Pin 1
Pin 2	Pin 2
Pin 3	Pin 3
Pin 6	Pin 6

Cross-over Cable Wiring	
Pin 1	Pin 3
Pin 2	Pin 6
Pin 3	Pin 1
Pin 6	Pin 2




Ethernet Plug & Connector Pin Positions

RJ45 Cable Distance

The maximum cable length for 10/100/1000BaseT is typically 100 meters (328 ft.).

Gig SFP Ports 9-12

Ports 9 -12 are gigabit ports that provide SFP (Small Form-factor Pluggable) connectors. This allows you to use the RJ45 connectors for twisted pair copper connections or use the SFP connectors for fiber optic connections. The SFP connectors support 100 Mbps and 1000 Mbps fiber optic transceivers for links up to 120 Km.



Note: For ports 9 and 10 you can only use one of the connectors (RJ45 or SFP) at a time. If you connect to both at the same time then neither connector may work.

Fast SFP Ports 1-8

Ports 1 through 8 offer flexible SFP (Small Form-factor Pluggable) connectors that support 10/100 Mbps RJ45 copper or 100 Mbps fiber optic SFP transceivers. On these 8 ports you can mix and match copper and fiber as desired.



Typical SFP Transceivers

The SFP transceivers just plug into the SFP cages. To lock them in place lift the locking arm as shown in the image above. To remove a transceiver, first pull down on the locking/release arm and then pull the transceiver out. The transceivers are “hot-swappable” meaning they can be plugged in or removed when the switch is powered.

The SFP ports accept fiber optic SFP transceivers. These transceivers are sold separately and are available as multimode, singlemode, long-haul (up to 120 Km or more), BiDi (bidirectional), WDM and other special types. They typically are offered with an LC style fiber connector. Refer to the datasheets for these transceivers for more details.

Fiber Wiring Guidelines



Typical Fiber SFP Transceiver and Dual-LC Cable

Use standard fiber optic wiring techniques (not covered by this manual) to make your connections. The corresponding LED will be ON solid or flashing when you have made a proper connection.

Duplex Operation

The RJ45 ports will auto-sense for Full or Half duplex operation, while the fiber ports default to full duplex operation or can be configured for Full or Half duplex. Refer to the software user manual for details on the software configuration options.

Verifying Connectivity


After all Ethernet and/or fiber connections are made, check the LED's corresponding to the ports that each of the devices are connected to. Ensure that for each port that is in use, the LED is on or blinking. If a port LED is off, go back and check for connectivity problems between that port and the network device connected to that particular port.

Console Port Management

The switch can be software configured via the DB9M (DB9 male) RS232 console ports. There is one of these ports located on each of the front and back of the switch. See the images below. This manual only details on how to connect to this port. Refer to the software manual for details on how to configure the switch via this port.



RS232 DB9M Ports




RS232 DB9M Port Closeup

Serial DB9 Console Port

The switch has a standard RS232 male DB9 serial port as shown in the previous images. The pin-outs are defined below. Use a standard “null-modem” cable between your PC and the switch. This cable is not supplied but is available from any computer store. If your PC does not have a serial DB9 port then you can purchase an inexpensive USB to Serial converter from any computer store, or use the USB port on the switch.

Switch DB9 Female		Typical Null-modem Cable DB9F to DB9F	PC DB9 Female	
DB9M Pin #	Signal Name		Signal Name	DB9M Pin #
1	CD in		CD in	1
2	RD in		RD in	2
3	TD out		TD out	3
4	DTR out		DTR out	4
5	GND		GND	5
6	DSR in		DSR in	6
7	RTS out		RTS out	7
8	CTS in		CTS in	8
9	RI in		RI in	9



Section 6

LED Indicators

Overview

The EL212 switches have 1 or 2 communication LEDs for each port, dual power LEDs, an “OK” output LED and an overall status LED.



LED Location

All Ports

All 28 ports each have only 1 LED. Regardless of the type of port (RJ45 versus SFP) or type of transceiver the LED behaves as follows:

Green LED ON Solid	Link Only - Indicates that there <u>is</u> a proper Ethernet connection (Link) but no communications activity is detected.
Green LED ON Flashing	Link & Activity - Indicates that there <u>is</u> a proper Ethernet connection (Link) and communications activity is detected.
OFF	No link - Indicates that there <u>is not</u> a proper Ethernet connection (Link). Make sure the cable has been properly connected at both ends.

Status LED

The Status LED indicates the overall health of the switch. It is normally ON solid indicating that no internal CPU or software problems are detected. It will flash on power up or reset. Otherwise, if it is OFF or flashing for an extended period of time then a problem is detected. In this case, please contact Red Lion for support.

Power LEDs

There are two Power LEDs (labeled Pwr 1 for primary power and Pwr 2 for backup power) that indicate if there is power applied to the respective input.

“OK” Alarm LED


The “OK” LED indicates the status of the alarm relay output. This LED will be normally ON when there is no alarm or error condition (such as loss of a power input). Otherwise, when there is an alarm then it will be OFF.

Section 7

Reset Button

Reset Button

A reset button has been provided in the event that a full hardware reset of the switch is required. The reset button is accessed through a small hole in the front of the switch near the status LED. See the image below. Simply use a straightened paper clip to push in the reset button. There is one mode of operation as described below.



Hardware Reset

To simply perform a hardware reset just push in the reset button momentarily. The switch will then immediately perform a hardware reset which takes around 2 minutes. The switch will not function or be accessible during this period.

Section 8

Technical Specifications

Technical Specs

These specifications are subject to change. Contact Red Lion for the latest details. Refer to the software user manual or datasheet for complete software specifications.

ETHERNET PERFORMANCE

- 12 total Ethernet ports
- 8 100BASE-X SFP ports
- 4 Gigabit with 2 10/100/1000 RJ45 ports and 2 RJ45/SFP combo ports
- RJ45 ports: auto-negotiation (speed/duplex) and auto-crossover
- Non-blocking, store and forward, wire-speed
- Switching capacity and forwarding rate: 12.8 Gbps / 9.5 Mpps
- MAC address table size: 16K
- Jumbo frame: 10K on Gigabit ports
- Ethernet isolation: 1500 Vrms 1 minute

SWITCHING FEATURES

- Flow control: IEEE 802.3x (Full Duplex) & Back-Pressure (Half Duplex)
- Spanning Tree Protocol (STP per IEEE 802.1D) plus
 - IEEE 802.1w Rapid Spanning Tree Protocol (RSTP)
 - IEEE 802.1s Multiple Spanning Tree Protocol (MSTP)
 - BPDU forwarding and filtering
- Real-Time-Ring™ for high speed fault-tolerant rings
 - Link loss recovery: 50 ms/hop
 - Switches in ring: <50 for best performance
 - Multiple rings are supported (up to 4)
- Virtual Local Area Networks (VLANs)
 - 802.1Q tag-based with 256 VLANs and 4K VLAN ID
 - 802.1v protocol and port-based VLAN
 - Voice and Private VLAN
 - QVRP and Q-in-Q (double tagging)
- Link Aggregation Control Protocol (LACP per IEEE 802.3ad)
 - Static trunk (8 trunks and up to 8 ports per trunk)
 - Traffic load balancing
- Internet Group Management Protocol (IGMP)
 - IGMP v1, v2 and v3 with up to 255 multicast groups
 - IGMP snooping and querying
 - Immediate leave and leave proxy
 - Throttling and filtering
- Multicast VLAN Registration (MVR)
- IEEE 802.1ab Link layer Discovery Protocol (LLDP)
- Quality of Service (QoS) with 4 priority queues
 - Scheduling schemes: WRR and Strict priority
 - CoS per IEEE 802.1p and IP DSCP-based
 - DiffServ (DS): ingress, egress and remarking
- Rate limiting (ingress and egress)
 - 64Kbps to 100/1000Mbps
 - Per port CoS

SECURITY

- Enable / disable ports
- Port security (MAC-based): static and dynamic
- DHCP Snooping and Option 82
- IP Source Guard
- IEEE 802.1x Network Access Control
 - Port-based with single or multiple host mode
 - Authentication: EAP-MD5, PEAP, TLS, TTLS
 - MAC and web authentication
 - Guest VLAN and Auto VLAN assignment
- RADIUS and TACACS AAA
 - Authentication, Accounting and Authorization
 - 5 servers for RADIUS, 1 server for TACACS
 - Encryption: MD5, TLS, TTLS, TACACS AAA/3.0
- Access Control List (ACL)
 - IP and MAC-based
 - VLAN and TCP/UDP port
- Storm Control for broadcast and multicast messages
- HTTPS/SSL for secure Web access
- SSH v1.5/2.0 for secure Telnet access
- SNMPv3 authentication and encryption
- Username and password authentication
- Management access filtering

MANAGEMENT AND MONITORING

- IP Address assignment: Static, DHCP and BOOTP
- CLI (Command Line Interface) via console or Telnet
- Web interface (HTTP/HTTPS/SSL)
- SNMP v1, v2, v3 (Simple Network Management Protocol)
- SNMP Traps for event notification
- RMON (Remote Monitoring): Groups 1, 2, 3 and 9
- sFlow network-wide traffic monitoring
- Dual firmware update system
- Configuration download and upload
- Software upgrade via TFTP
- Port mirroring
- Event / Error / System log
 - Local flash
 - Remote server via system log (Syslog RFC 3164)
 - SMTP (RFC 821) email alarming
- Network Time Protocol for time synchronization
 - NTP (RFC 2030) and NTP (RFC 1305)
- DNS (Domain Name Server) client
- Universal Plug and Play (UPnP)
- IEEE 802.3ah OAM (Operational Administration Maintenance)
- Banner commands

POWER INPUT and ALARM OUTPUT

- Dual-redundant internal power supplies
- 10-pole screw block can be positioned in front or back
- Power input options:
 - +/-24-48 VDC (D option) **(absolute min and max):**
+/-18-75 VDC
 - +/-110-250 VDC or 100-240 VAC (50/60 Hz)(A option) **(absolute min and max):** +/-90-300 VDC or 85-264 VAC
- Power consumption:
 - 60 Watts typ. w/ all ports linked
 - 28 Watts with no transceivers
 - Add 1.25 Watts typical per transceiver
- Protection: current overload and reverse polarity
- Alarm output: form-C relay (NO and NC contacts)
 - Max. voltage: 250 VAC, 30 VDC
 - Max. current: 2A @ 30 VDC or 250 VAC

MECHANICAL

- Universal mounting: (Sixnet-exclusive feature – Patent Pending!)
 - Front or rear/reverse wiring with power in front or back
 - 1U rack mount (19" brackets included)
 - Optional 23", 24", EIA, WECO, ETSI and wall brackets available
- Ingress protection: IP50 sealed from dust and contaminants
- Heavy-gauge corrosion-resistant metal enclosure
- Dimensions (HxWxD): 1.75(1U)x17.3x12" (45x439x305mm)
- Weight (typical): 5.5 lbs (2.5 kg)

ENVIRONMENTAL

- Operating/storage temperature: Designed and tested to -40 to +85°C per IEC 60068-2-1/2
- Humidity: 5 to 95% RH (non-condensing) per IEC 60068-2-78
-
- **Vibration: 20mm/s from 1 to 150 Hz per IEEE 1613 Class V.S.3**
- **Vibration: Amp: 3mm from 2-9 Hz, 1g from 9-200Hz, 1.5g from 200-500 Hz per IEC 61850-3**
- **Shock: 30g @ 11ms per IEC 61850-3**
- Shock - Free Fall: 250mm distance

EMC and STANDARDS COMPLIANCE

- Substation: IEC 61850-3 / IEC 60870-2-2; IEEE 1613
- EMC immunity: IEEE C37.90 and c37.90.1/2/3; IEC/TS 61000-6-5, IEC 60870-2-1, IEC 61000-4 2/3/4/5/6/8/10/11/12/16/17/18/29, IEC 60255-5, CE
- EMC emissions: FCC Part 15; EN 55022 (CISPR22), CE
- **Safety: UL508 / ANSI / ISA12.12.01/CSA C22.2 142/213. EL212F-DC-V1, T4 @ 85C (Surrounding Air); EL212F-AC-V1, T3C @ 50C (Surrounding Air). EN61010-1, Zone 2 (ATEX). Only the EL212F-DC-V1 is approved for Zone 2 (ATEX) areas.**
- RoHS, WEEE and CE compliant
- ISO9001:2008 certified company
- Warranty: 5 years on design and manufacturing defects
- MTBF A0/D0 models: 208,166 Hours GB @ 40°C per MIL-HNDBK-217F2
- MTBF AA/DD models: 204,345 Hours GB @ 40°C per MIL-HNDBK-217F2

Section 9

Service Information

Service Information

We sincerely hope that you never experience a problem with any Red Lion product. If you do need service, call Red Lion at 1-877-432-9908 for Technical Support. A trained specialist will help you to quickly determine the source of the problem. Many problems are easily resolved with a single phone call. If it is necessary to return a unit to us, an RO (Repair Order) can be obtained on the [Red Lion website](#).

Red Lion tracks the flow of returned material with our RO system to ensure speedy service. You must include this RO number on the outside of the box so that your return can be processed immediately.

Be sure to have your original purchase order number and date purchased available.

We suggest that you give us a repair purchase order number in case the repair is not covered under our warranty. You will not be billed if the repair is covered under warranty.

Please supply us with as many details about the problem as you can. The information you supply will be written on the RO form and supplied to the repair department before your unit arrives. This helps us to provide you with the best service, in the fastest manner. Repairs are completed as soon as possible. If you need a quicker turnaround, ship the unit to us by air freight. We give priority service to equipment that arrives by overnight delivery.

We apologize for any inconvenience that the need for repair may cause you. We hope that our rapid service meets your needs. If you have any suggestions to help us improve our service, please give us a call. We appreciate your ideas and will respond to them.

For Your Convenience:

Please fill in the following and keep this manual with your Red Lion system for future reference:

P.O. #: _____ Date Purchased: _____

Purchased From: _____

Product Support

To obtain support for Red Lion products:

Latest product info: <http://www.redlion.net>

Phone: 1-877-432-9908

Fax: 1 -518-877-8346

E-mail: support@redlion.net

Address: Red Lion Controls, 20 Willow Springs Circle, York, PA 17406

This page intentionally left blank.