

THE APOLLO INTELLIGENT METER SERIES



MODEL IMH INSTRUCTION MANUAL

INTRODUCTION

The Intelligent Meter for 5 Amp AC input (IMH) is another unit in our multi-purpose series of industrial control products that are field-programmable to solve multiple applications. This series of products is built around the concept that the end user has the capability to program different personalities and functions into the unit in order to adapt to different indication and control requirements.

The Intelligent Meter which you have purchased has the same high quality workmanship and advanced technological capabilities that have made Red Lion Controls the leader in today's industrial market.

Red Lion Controls has a complete line of industrial indication and control equipment, and we look forward to being of service to you now and in the future.



CAUTION: Risk of Danger.
Read complete instructions prior to
installation and operation of the unit.



CAUTION: Risk of electric shock.


TABLE OF CONTENTS

GENERAL DESCRIPTION	2-3
A) Safety Summary	2
B) Block Diagram	3
C) Theory of Operation	4
PROGRAMMING AND OPERATING THE IMH	4-21
A) Programming the IMH	4-5
B) Program Modules #1 thru #9	6-17
C) Operating the IMH (Quick Programming)	18
D) Factory Configuration	19
E) Programming Example	20
F) Motor Monitoring Example	21
TOTALIZER/LINEARIZER/PEAK/VALLEY/TARE (Optional)	22-24
A) Totalizer Example	22-23
B) Linear Segmenting Example	23-24
ALARMS (Optional)	25
RE-TRANSMITTED ANALOG OUTPUT (Optional)	26-27
APPENDIX "A" - INSTALLATION AND CONNECTIONS	28-30
A) EMC Installation Guidelines	29
B) Select AC Power (115/230 VAC)	29
APPENDIX "B" - SPECIFICATIONS AND DIMENSIONS	31-32
APPENDIX "C" - TROUBLESHOOTING GUIDE	33
APPENDIX "D" - PROGRAMMABLE FUNCTIONS	34-35
APPENDIX "E" - ORDERING INFORMATION	36

GENERAL DESCRIPTION

The Apollo Intelligent 5 Amp AC Current Meter (*IMH*) accepts AC currents up to 5 amps and precisely scales them into engineering units with high resolution. With the use of an external 5 amp AC current transformer, of any ratio, currents of any magnitude can be measured and displayed. The meter is calibrated from the factory to display RMS value of a pure sinusoidal signal. The input is AC coupled to eliminate any DC effects in the signal. True RMS readings are not obtained from complex waveforms, such as square waves, signals that have been rectified or chopped due to a circuit with an SCR or Triac outputs. These kind of complex waveforms will cause average value readings.

Examples of such waveforms are shown below:



Example A is an undistorted sinewave and the IMH will indicate true RMS. With the complex waveforms shown in Examples B and C, the meter will indicate average value.

Internal resolution of 1 mA allows detection and indication of the smallest signal change. A two Hz, two pole, low-pass filter coupled with programmable digital filtering can be tuned to match the characteristics of any process. A digital tare (*re-zero*) operation can be performed at a touch of a button along with recall of process peak and valley (*max/min*). State-of-the-art digital circuitry virtually eliminates errors due to drift. A full complement of option packages is available to fulfill many process applications.

The indicator features a choice of two different scaling procedures which greatly simplifies initial set-up. A full 6-digit display accommodates virtually any process engineering unit. English-style display prompts and front panel buttons aid the operator through set-up and operation. A front panel lock-out menu protects set-up data and operation modes from unauthorized personnel. Programmable remote input "*E1-CON*" can be utilized to control a variety of totalizing, alarm control, display hold and tare operations. All set-up data is stored in E²PROM, which will hold data for a minimum of 10 years without power.

An optional integrator (*totalizer*)/linearizer can be used to totalize or integrate signals up to a maximum display value of 999999. It features independent scaling and a low signal cut-out to suit a variety of signal integration applications. Programmable remote input "*E2-CON*" pin is included with this option and can be utilized to control a variety of functions, such as totalizing, alarm control, peak/valley readings, display hold or tare operations, simultaneously with "*E1-CON*" pin. Additionally, nine slopes and offsets can easily be programmed to linearize processes with non-linear outputs, such as square law devices. Peak/valley (*max/min*) reading memory, and a signal re-zeroing (*tare*) function are included and they are easily recalled and controlled by the front panel. All readings are retained at power-down.

Optional dual relays with parallel solid state outputs are fully programmable to operate in a wide variety of modes to suit many control or alarm applications.


An optional 4 to 20 mA or 0 to 10 VDC re-transmitted analog output can be scaled by the user to interface with a host of recorders, indicators and controllers. The type of analog output is determined by the model ordered. (See Ordering Information for available models.) The indicator has several built-in diagnostic functions to alert operators of most any malfunction. Extensive testing of noise interference mechanisms and full burn-in makes the indicator extremely reliable in industrial environments. The die-cast front bezel meets NEMA 4/IP65 requirements for washdown applications, when properly installed. Plug-in style terminal blocks simplify installation and wiring change-outs.

SAFETY SUMMARY

All safety related regulations, local codes and instructions that appear in the manual or on equipment must be observed to ensure personal safety and to prevent damage to either the instrument or equipment connected to it. If equipment is used in a manner not specified by the manufacturer, the protection provided by the equipment may be impaired.

Do not use this unit to directly command motors, valves, or other actuators not equipped with safeguards. To do so, can be potentially harmful to persons or equipment in the event of a fault to the unit.

FIG. 1: BLOCK DIAGRAM



Note: Analog (-) and Alarm common are separate and isolated from the signal common.
 The commons should NOT be tied together. Check label for wiring connections.

THEORY OF OPERATION


The IMH employs a microprocessor to perform the A/D conversion on the input signal via a voltage-to-frequency converter. It digitally scales the result, corrects for meter drift which may be present and then displays the result in a 6-digit display (5 for input, 6 for totalizer). The inputs are filtered to enhance the stability of the display. A non-volatile E²PROM memory device provides permanent data retention for operating variables. The display consists of drivers and 6-digit solid-state LEDs. The alarm option employs opto-isolators to isolate the open collector devices from meter common. Operating in parallel, the relays are type Form-C and are rated at 5 Amps. The analog option features a 12-bit DAC and provides an output signal that is digitally scaled. The re-transmitted output is isolated from meter common.

PROGRAMMING THE IMH

Prior to installing and operating the indicator, it may be necessary to change the scaling to suit the display units particular to the application. Although the unit has been pre-programmed at the factory, the set-ups will generally have to be changed.

The indicator is unique in that two different scaling methods are available. The operator may choose the method that yields the easier and more accurate calibration. The two scaling procedures are similar in that the operator keys-in two display values and either keys-in or applies a signal value that corresponds to those display points (see FIG. 2). The location of the scaling points should be near the process end limits, for the best possible accuracy. Once these values are programmed (coordinates on a graph), the indicator calculates the slope and intercept of the signal/display graph automatically. No span/zero interaction occurs, making scaling a one-pass exercise. Basic scaling is complete after decimal point selection, unit rounding (dummy zeros) and digital filtering level selection. The following procedure should be followed to scale the indicator.

FIGURE 2: SLOPE DIAGRAM



NOTE: STARTING POINT OF SLOPE DIAGRAM IS ALWAYS ZERO (0).

Before actually trying to program the indicator, it is advised to organize all the data for the programming steps to avoid any possible confusion and to read the programming procedure entirely before proceeding.

To set-up the indicator, connect AC power and signal wires as outlined in the connections section (Appendix "A"). Remove the jumper wire (if installed) from TBA #3 (PGM. DIS.). This will allow the operator to enter and modify all of the indicator's parameters. Press the front panel button labeled "P", momentarily. Briefly, the display will show "Pro" alternately flashing with "0". This is the indicator's programming mode. The programming mode is divided into sections, numbered 0-9, each of which can be individually accessed. The front panel "UP" and "DOWN" arrow buttons can be used to select one of these numbers and the "P" button used to enter the selected programming module. In all of the programming modules, "UP" and "DOWN" are used to either select from a list of choices or enter a value. The "P" button is used to save the new value and progress to the next step within a module (Note: the new value takes effect when "P" is pressed). Upon completion of a module, the indicator returns to the "Pro" <> "0". Pressing the "P" button at this point causes the unit to display "End", after which the unit returns to normal mode. The following table explains the basic function of each step.

Note: < > This indicates that the display will alternate between the English prompt and the actual data.

DISPLAY

RESULT OF "P" BUTTON

- "Pro"<>"0" - Causes the indicator to return to normal display mode. Any changes to set-up data are permanently stored in the E²PROM.
- "Pro"<>"1" - Entry into this module allows the user to select the decimal point position, unit rounding and scaling by the method of applying the actual signal levels to the indicator that corresponds to the programmed display values. Use this method when the indicator is connected to the process and the process can be brought to known levels. Alternately, a precision AC current source may be substituted to simulate the process. A second method is available in Pro 2.
- "Pro"<>"2" - Entry into this module allows the user to select the decimal point position and unit rounding, as in Pro 1, but the method of scaling differs in that the user keys in signal levels instead of applying signals to the indicator. Use this method when the process (*signal source*) is calibrated with known display values at known signal levels. An alternate method is available in Pro 1.
- "Pro"<>"3" - Module #3 allows the user to program what can be accessed from the front panel when the PGM. DIS. (*Program Disable, TBA #3*) pin is connected to common. This feature protects critical set-up data from accidental modification while allowing access to setpoints and other functions. The front panel lock-out menu (*quick programming*) includes setpoint modification, totalizer resetting, zeroing the input and peak/valley resetting.

Note: The term "Quick Programming" is used to refer to the ability to change the information that can be accessed from the front panel when the "PGM. DIS." terminal is connected to "COMM."

DISPLAY

RESULT OF "P" BUTTON

- "Pro"<>"4" - Module #4 programs the digital filtering level and the function of the remote input "E1-CON" pin (*TBA #4*) and if the totalizer option is installed the remote input "E2-CON" pin (*TBA #7*). The functions of the remote E1 and E2 pins are the same and include display hold, peak/valley modes, totalizer reset, alarm reset, signal re-zero (*tare*) reading synchronization or print request.
- "Pro"<>"5" - This module sets the decimal point position, time base, scale factor and low signal disable function for the totalizer/integrator.
- "Pro"<>"6" - This module allows programming for the basic configuration of the alarm option. The programming includes HI/LO acting, tracking, alarm display, latched or auto-reset, assignment to either signal or integrator/totalizer and alarm and hysteresis values.
- "Pro"<>"7" - Not used
- "Pro"<>"8" - This module allows digital scaling of the re-transmitted analog output. Display values that correspond to 4 mA or 0 VDC and 20 mA or 10 VDC are keyed-in to scale the output and it may be assigned to either the signal or the integrator/ totalizer.
- "Pro"<>"9" - This module is the service operations sequence and is not normally accessed by the user. This step re-calibrates the basic input and is used to compensate for long-term drift. Execution of this module should be done by technicians with the proper equipment in accordance with a maintenance plan of yearly re-calibrations. A code number entry step is used to protect from inadvertent entries. Also, there is a number of other access codes, which provide test and set-up changes as an aid in troubleshooting.

PROGRAMMING MODULE #1 - SCALE BY SIGNAL LEVEL METHOD

PROGRAM DECIMAL POINT POSITION

Select the desired decimal point position of the scaled display by pressing either the “Up” or “Down” button.

Note: Whatever decimal point is selected will appear in succeeding programming steps. Also, the “P” button must be pressed after each step to enter the desired data and to proceed to the next step.

“dECPnt” <> “0”
“0.0”
“0.00”
“0.000”
“0.0000”

PROGRAM ROUNDING INCREMENT AND RIGHT HAND DUMMY ZEROS

Rounding values other than one cause the scaled number to ‘round’ to the nearest rounding increment selected (i.e. rounding of ‘5’ causes ‘122’ to round to ‘120’ and ‘123’ to round to ‘125’). If the process is inherently jittery, the display value may be rounded to a value higher than one. If the range of the process exceeds the required resolution, (ex. 0-3.000 AMPS AC, but only 0.010 AMP AC resolution required), a rounding increment of 10 will effectively make the display more stable. This programming step is usually used in conjunction with programmable digital filtering (Pro 4) to help stabilize display readings. (If display stability appears to be a problem and the sacrifice in display resolution is unacceptable, program higher levels of digital filtering or increase the level of process dampening.) Rounding increments of 10, 20, 50, and 100 may also be used to add “dummy zeros” to the scaled readings, as desired.

“round” <> “1”
“2”
“5”
“10”
“20”
“50”
“100”

At this stage, a choice of either to return to “Pro 0” or to continue with scaling of the display is offered.

“SCALE” <> “YES”
“NO”

If “YES” was selected for the previous step, the scaling procedure is started. In order to scale the indicator, two signal level values and two display values that correspond to the signal values must be known. These four values are used to complete the scaling operation. An example of a signal-display pair is listed below:

0.00 % @ 0.000 Amps AC AND 100.00 % @ 5.000 Amps AC
Scaling point #1 Scaling point #2

KEY-IN DISPLAY VALUE FOR SCALING POINT #1

“dSP 1” <> “-99999” to “99999” (ex. 0.00 %)

APPLY SIGNAL TO INDICATOR FOR SCALING POINT #1

The meter will indicate the actual amount of signal being applied to the input. However, the indicator still retains the previously applied value until “P” is pressed, at which time the new value is stored. Pressing either the “UP” or “DOWN” button causes the previous value to remain programmed in the unit.

“INP 1” <> “0.000 to 5.000 Amps AC” (ex. 0.000)

KEY-IN DISPLAY VALUE FOR SCALING POINT #2

“dSP 2” <> “-99999” to “99999” (ex. 100.00 %)

APPLY SIGNAL TO INDICATOR FOR SCALING POINT #2

The meter will indicate the actual amount of signal being applied to the input. However, the indicator still retains the previous value until “P” is pressed, at which time the new value is stored. Pressing either the “UP” or “DOWN” button causes the previous value to remain programmed in the unit.

“INP 2” <> “0.000 to 5.000 Amps AC” (ex. 5.000)

The indicator will be ready to accept more scaling points (*if more are desired*) for multisegment linearization. The quantity and location of the linearization points should be chosen very carefully to best utilize the segments available. Refer to the section on linearization for a discussion on this matter.

At this stage, scaling is complete. The indicator will automatically calculate the slope and offset of the display units. After completing Pro 1, it is recommended that the scaling operation be verified by applying various signals and checking the displayed reading.

PROGRAM NUMBER OF LINEAR SEGMENTS

This programming step loads in the number of linear segments desired for multisegment linearization. If single slope scaling is desired, input "1" for this step. If two segments are desired, input "2", etc. You must have one more scaling point known than the number of segments selected (*ie. 1 segment = 2 points, 2 segments = 3 points, etc*). This step may be used to deactivate previously programmed segments where lower segments would override higher segments. (*ex. changing "SEgt" from 5 to 3 causes slopes 4 & 5 to be replaced by an extension of slope 3*).

"SEgt"<>"1" - "9"

If "1" was selected, the indicator will return to "Pro 0" since scaling for the first segment was already completed. Otherwise, a choice of either returning to "Pro 0" or commencing with the multislope linearization scaling is offered.

"SCALE" <> "yES"
"NO"

KEY-IN DISPLAY VALUE FOR POINT #3

If "YES" was selected, the display value for the third point is entered. Otherwise, the indicator returns to "Pro 0".

"dSP 3" <> "-99999" to "99999"

APPLY SIGNAL TO INDICATOR FOR POINT #3

The signal level value for point 3 is applied.

"INP 3" <> "0.000 to 5.000 Amps AC"

The sequence of entering display and signal values continues with "dSP 4", "INP 4", "dSP 5", etc. until the number programmed for "SEgt" is reached. Upon completion, the indicator is scaled to the multiple segments. It is recommended that the scaling be checked by exiting the programming mode and applying signal values and verifying for correct display values.

** Note As the "UP" or "DOWN" button is continually held in, the display will progressively increment faster until the fourth most significant digit is changing at a rate of 1 number per second.*

PROGRAMMING MODULE #2 - SCALE BY KEY-IN METHOD

PROGRAM DECIMAL POINT POSITION

Select the desired decimal point position of the scaled display by pressing either the “Up” or “Down” button.

Note: Whatever decimal point is selected will appear in succeeding programming steps. Also, the “P” button must be pressed after each step to enter the desired data and to proceed to the next step.

“dECPNt” <> “0”
“0.0”
“0.00”
“0.000”
“0.0000”

PROGRAM ROUNDING INCREMENT AND RIGHT HAND DUMMY ZEROS

Rounding values other than one cause the scaled number to ‘round’ to the nearest rounding increment selected (*ie. rounding of ‘5’ causes ‘122’ to round to ‘120’ and ‘123’ to round to ‘125’*). If the process is inherently jittery, the display value may be rounded to a higher value than one. If the range of the process exceeds the required resolution, (*ex. 0-3.000 AMPS AC, but only 0.010 AMP AC resolution required*), a rounding increment of 10 will effectively make the display more stable. This programming step is usually used in conjunction with programmable digital filtering (*Pro 4*) to help stabilize display readings. (*If display stability appears to be a problem and the sacrifice in display resolution is unacceptable, program higher levels of digital filtering or increase the level of process dampening.*) Rounding increments of 10, 20, 50, and 100 may also be used to add “dummy zeros” to the scaled readings, as desired.

“round” <> “1”
“2”
“5”
“10”
“20”
“50”
“100”

At this stage, a choice of to either return to “Pro 0” or to continue with scaling of the display is offered.

“SCALE” <> “yES”
“NO”

If “YES” was selected for the previous step, the scaling procedure is started. In order to scale the indicator, two signal level values and two display values that correspond to the signal values must be known. These four values are directly entered into the indicator. An example of a signal-display pair is listed below:

0.00 % @ 0.000 Amps AC AND 100.00% @ 5.000 Amps AC
Scaling point #1 Scaling point #2

KEY-IN DISPLAY VALUE FOR SCALING POINT #1

“dsp 1” <> “-99999” to “99999” (ex. 0.00 %)

KEY-IN SIGNAL VALUE FOR SCALING POINT #1

“INP 1” <> “0.000 to 5.000 AMPS AC” (ex. 0.000)

KEY-IN DISPLAY VALUE FOR SCALING POINT #2

“dsp 2” <> “-99999” to “99999” (ex. 100.00%)

KEY-IN SIGNAL VALUE FOR SCALING POINT #2

“INP 2” <> “0.000 to 5.000 AMPS AC” (ex. 5.000)

The indicator will be ready to accept more scaling points (*if more are desired*) for multisegment linearization. The quantity and location of the linearization points should be chosen very carefully to best utilize the segments available. Refer to the section on linearization for a discussion on this matter.

At this point, scaling is complete. The indicator will automatically calculate the slope and offset of the display units. After completing Pro 2, it is recommended that the scaling operation be verified by applying various signals and checking the displayed reading.

PROGRAM NUMBER OF LINEAR SEGMENTS

This programming step loads in the number of linear segments desired for multisegment linearization. If single slope scaling is desired, program "1" for this step. If two segments are desired, program "2", etc. You must have one more scaling point known than the number of segments selected (*ie. 1 segment = 2 points, 2 segments = 3 points, etc*). This step may also be used to deactivate previously programmed segments where lower segments would override higher segments. (*ex. changing "SEGt" from 5 to 3 causes slopes 4 & 5 to be replaced by an extension of slope 3*).

"SEGt" <> "1 - 9"

If "1" was selected, the indicator will return to "Pro 0" since scaling for the first slope was already completed. Otherwise, a choice of either returning to "Pro 0" or commencing with the multislope-linearization scaling is offered.

"SCALE" <> "yES"
"NO"

If "yes" was selected, the display value for the third point is entered. Otherwise, the indicator returns to "Pro 0".

KEY-IN DISPLAY VALUE FOR SCALING POINT #3

"dSP 3"<>"-99999" to "99999"

KEY-IN INPUT VALUE FOR SCALING POINT #3

"INP 3"<>"0.000 to 5.000 AMPS AC"

The sequence of entering display and signal values continues with "dSP 4", "INP 4", "dSP 5", etc. until the number programmed for "SEGt" is reached. It is recommended that the scaling be checked by exiting the programming mode and applying signal values and verifying for correct display values.

Note: As the "UP" or "DOWN" button is continually held in, the display will progressively increment faster until the fourth most significant digit is changing at a rate of one number per second.

PROGRAMMING MODULE #3 - PROGRAM FUNCTIONS ACCESSIBLE WITH FRONT PANEL LOCKOUT

This programming module programs what is accessible through the front panel when the PGM.DIS. pin is connected to common (COMM. TBA #5).

Note: The term "Quick Programming" is used to refer to the ability to change the information that can be accessed from the front panel when the "PGM.DIS." terminal is connected to "COMM."

DISPLAY ALARM VALUES

If the alarm option is installed, this selects whether the alarm values will or will not be displayed.

"dSP AL" <> "yES" or "NO"

ENTER ALARM VALUES *

If "YES" was selected for display alarm values, this will select if alarm values may be modified from the front panel. (If "NO" was selected for display alarm values, then this step will default to "NO" and will not be displayed for selection.)

"ENt AL" <> "yES" or "NO"

DISPLAY HYSTERESIS VALUES

If the alarm option is installed, this selects whether the hysteresis values will or will not be displayed.

"dSPHYS" <> "yES" or "NO"

ENTER HYSTERESIS VALUES *

If "YES" was selected for display hysteresis values, this selects whether hysteresis values may be modified from the front panel. (If "NO" was selected for display hysteresis values, then this step will default to "NO" and will not be displayed for selection.)

"ENtHYS" <> "yES" or "NO"

RESET LATCHED ALARMS

If the alarm option is installed, this will select if a latched alarm(s) can be reset from the front panel.

"rSt AL" <> "yES" or "NO"

DISPLAY PEAK/VALLEY MEMORY BUFFER

If the totalizer/linearizer option is installed, this selects whether peak and valley buffers will be displayed.

"dSPbUF" <> "yES" or "NO"

RESET PEAK/VALLEY MEMORY BUFFER *

If "YES" was selected for the previous step, this selects whether the peak and valley buffers may be reset from the front panel. (If "NO" was selected, then this step defaults to "NO" and will not be displayed for selection.)

"rStbUF" <> "yES" or "NO"

SELECT DISPLAY **

If the totalizer/linearizer option is installed, this selects whether the display can be switched from input display to total display and from total display to input display.

Note: When "NO" is selected, the display mode that was being displayed before entering programming, will be the only display accessible.

"SELdSP" <> "yES" or "NO"

* This sequence may be subject to being locked out due to other programmed sequences.

** This function operates independent of the state of the "PGM.DIS." pin.

RESET TOTAL **

If the totalizer/linearizer option is installed, this selects whether the total can be reset from the front panel.

“rSttOt” <> “yES” or “NO”

RE-ZERO INPUT **

If the totalizer/linearizer option is installed, this selects whether the signal can be re-zeroed (*tared*) or not.

“tArE” <> “yES” or “NO”

Note: The tare buffer can be cleared by “walking” through “Pro 2”, using the P button.

Depending on functions selected under Pro 3 and Pro 6, alarms, hysteresis, peak, and valley values can be monitored and/or changed when PGM. DIS. is tied to COMM. This provides a “*QUICK PROGRAMMING*” method for “*day to day*” process changes. (See *QUICK PROGRAMMING SECTION* for more details.)

** This sequence may be subject to being locked out due to other programmed sequences.*

*** This function operates independent of the state of the “PGM.DIS.” pin.*

PROGRAMMING MODULE #4 - PROGRAM DIGITAL FILTER AND REMOTE INPUT

PROGRAM DIGITAL FILTERING

If the displayed process signal is difficult to read due to small process variations or noise, increased levels of filtering will help to stabilize the display. This programming step may be used in conjunction with display rounding programming (*Pro 1 & 2*) to help minimize this effect. The digital filter used is an “adaptive” filter. That is, the filter coefficients change dynamically according to the nature of the input signal. This feature simultaneously allows the filter to settle quickly for large input changes while providing a stable display reading for normal process variations. Because of the adaptive nature of the filter, it cannot be characterized in terms of a time constant. The following table lists the maximum settling time for a step input to within 99% of final value.

	<u>Filter Value</u>	<u>Settling Time (99%)</u>
“FILTEr” < >	“0” - no digital filtering	1.5 sec.
	“1” - normal filtering	2 sec.
	“2” - increased filtering	6 sec.
	“3” - maximum filtering	13 sec.

PROGRAM FUNCTION OF E1-CON AND OPTIONAL E2-CON PIN

The function of the remote input “E1-CON” pin (*TBA #4*) and, if the totalizer option is installed, the remote input “E2-CON” pin (*TBA #7*) are the same. Functions are activated, as described in the appropriate function, when connected to signal common (*TBA #5*). Whether a function is edge or level activated it must be held low for a minimum of 20 msec in order for the function to occur. The remote input pins can be used simultaneously and with any combination of functions. When pins are tied together and activated, E1-CON function is generally performed first.

“E1-CON” <> “0” - A negative going edge re-zeros (*tares*) the input signal.

Note: The tare buffer can be cleared by “stepping” through “Pro 2”, using the P button.

“1” - A negative going edge resets the contents of the totalizer to zero. Totalization commences regardless of the state of the input.

“2” - A negative going edge resets the contents of the totalizer to zero and allows totalization as long as the input is low. If the

input goes high, totalization is stopped and the contents are saved. This acts as a totalization enable control from time T1 to T2.

“3” - A low level allows totalization from the previously saved contents as long as the input is low. If the input goes high, totalization is stopped and the contents are saved. This acts as a totalization enable control from time T1 to T2.

“4” - A low level holds the display (*display hold*). While this input is low, the indicator continues to process the input signal and drive the alarms, totalizer, etc. with the actual signal. The contents of the totalizer are stored at the same time when the input display is held.

Note: If display hold is activated, and input value was showing in the display, the operator can switch to total value by pressing the up button.

“5” - A negative going edge resets both peak and valley buffers.

Note: After P/V is called up, a change will not appear on the display until the next time the P/V is called up.

“6” - A negative going edge resets only the peak buffer and the indicator enters a peak reading display mode as long as the input is low. If the input goes high, peak detection and indication is stopped and the last peak reading is retained.

“7” - A negative going edge resets only the valley buffer and the indicator enters a valley reading display mode as long as the input is low. If the input goes high, valley detection and indication are stopped and the last valley reading is retained.

“8” - If the alarm option is installed, a negative going edge resets the latched alarm(s).

“9” - If the alarm option is installed, a low level resets a latched or unlatched alarm into its inactive state. This provides manual override of alarms for system start-up and other unusual events such as system testing.

“10” - A negative going edge toggles the display between “input” and “total” (*from input to total, or vice versa*). No action is taken on the positive going edge.

“11” - A negative going edge zeros (*tares*) the input signal and adds the value that was in the input display to the totalizer value every time this operation is performed. The time-base, scale factor and low cut-out in “Module #5” are in effectively disabled, when this function is selected

“12” - Display hold with tare. A negative going edge tares (*zeros*) the input signal. Prior to the tare operation, the input signal is saved and held (*display hold*) as long as the remote input pin is low. On the positive edge the input display will show zero. If there is an increase to the input signal while the remote input is

low, the display will reflect (*show*) the increase at the positive edge.

“13” - Instrument reading synchronization. A low level disables all meter operations (*alarms, total, analog out, etc.*). A positive edge resets the start of the A/D conversion, to allow synchronization with external process and controls. While in this function, the other E-CON pin is operational.

“E2-CON” <> - If the E2-CON option is installed, E2-CON has the same programmable functions as E1-CON.

PROGRAMMING MODULE #5 - PROGRAM TOTALIZER / INTEGRATOR

Programming for the totalizer/integrator consists of four programming steps: decimal point position, time base, scale factor and low signal disable. Note that the decimal point position of the integrator/totalizer can be set independent of the decimal point position of the input. The totalizer will roll over and flash when the total exceeds, 999999 or -99999, indicating an overflow condition.

PROGRAM DECIMAL POINT POSITION FOR THE TOTALIZER

The decimal point positions for the totalizer are as follows:

“dECPNt” <> “0”
 “0.0”
 “0.00”
 “0.000”
 “0.0000”

PROGRAM TOTALIZER/INTEGRATOR TIME BASE

The time base determines the rate at which readings increase. The totalizer display is updated 2 1/2 times per second regardless of time base selected, but longer time bases decrease the magnitude of each increase. The three time bases are per second, per minute and per hour. A constant signal input of 1000 units, for example, would totalize to 1000 units in one second (*with a TB of 1 sec.*), 1000 units in one minute (*with a TB of 1 min.*), and 1000 units in one hour (*with a TB of*

1 hr.).

Note: Input changes can be made synchronous to the display by programming E1 or optional E2-CON pin for function 13, Instrument reading synchronization.

A multiplying scale factor may be used to span the standard time ranges (*or divide if scale factor < 1*). The following equation expresses the totalization process.

$$\text{S.F.} = \frac{\text{D.T.}}{\text{I.D.}} \times \frac{\text{T.B.}}{\text{TIME}} \times \frac{\text{D.T.D.P.}}{\text{I.D.D.P.}}$$

S.F. = Programmable Scale Factor
 D.T. = Desired Totalizer Value for a fixed time duration
 T.B. = Programmable Time Base

<u>If Program Select Number Chosen Is:</u>	<u>Enter in Formula</u>
“0” for sec.	1
“1” for min.	60
“2” for hr.	3600

I.D. = Input Display Value
 TIME = Actual Time period in seconds

PROGRAMMING MODULE #5 - PROGRAM TOTALIZER / INTEGRATOR (Cont'd)

D.T.D.P. = Desired Totalizer Decimal Point

	<u>Enter in Formula</u>
0	1
0.0	10
0.00	100
0.000	1000
0.0000	10000

I.D.D.P. = Input Display Decimal Point

	<u>Enter in Formula</u>
0	1
0.0	10
0.00	100
0.000	1000
0.0000	10000

“tbASE” <> “0” - per second
“1” - per minute
“2” - per hour

PROGRAM THE TOTALIZER SCALE FACTOR

As explained in the previous programming step, a multiplying scale factor can be used to scale the update rate as required. This may be used to span the standard ranges. A scale factor of “1.000” has no effect on the standard ranges.

“SCLFAC” <> “0.001” to “100.000”

PROGRAM THE LOW-END CUTOUT (low signal level disable)

In order to prevent false totalization during system start-up or other low process situations where totalization is undesirable, a programmable setpoint can be used to disable totalization when the scaled input signal falls below this low-end cutout level.

“Lo-cut” <> “-99999” to “999999”

PROGRAMMING MODULE #6 - PROGRAM ALARM / SETPOINT

If the alarm option is installed, this module is used to configure the operation of the alarms to a variety of combinations. The programmable options are HI/LO acting, auto/manual reset (*latching*), tracking, assignment to signal or totalizer, display alarms, alarm values and hysteresis (*deadband*) values.

ALARM TRACKING

With alarm tracking, whenever alarm #2 is changed, alarm #1 will also change so that the offset between alarm #2 and alarm #1 remains the same. This is useful for hierarchical setpoints (*pre-alarm and alarm*) when one change applies to both alarm values. When programming from the front panel, tracking only occurs when PGM.DIS. is low (*front panel lock-out mode, alarm #1 will not appear*).

“trAc” <> “yES” or “NO”

DISPLAY ALARMS

If display alarms are desired, a message will flash on the display every 5-10 secs when an alarm activates. For Alarm 1 the message will flash “AL1 on” and alarm 2 will flash “AL2 on”, this warns an operator of an alarm condition. The message will stop when the unit is no longer in an alarm condition.

“dISP” <> “yES” or “NO”

AUTO OR MANUAL RESET FOR ALARM #1

The reset action of alarm #1 may be programmed to reset automatically (*unlatched*) or be programmed to require a manual reset (*latched*), through either a remote input (*Pro 4, E1-CON or optional E2-CON*) or through the front panel (*Pro 3, reset latched alarms*). Latched alarms are usually used when an operator is required to take some action for the alarm condition.

“LAtC-1” <> “yES” or “NO”

ALARM #1 ASSIGNMENT TO INPUT SIGNAL OR TOTALIZER

Alarm #1 may be programmed to activate on either the input signal or the totalizer value. If the totalizer option is not installed, this step defaults to the input.

“ASN-1” < > “INPUt” or “totAL”

PROGRAM VALUE FOR ALARM #1

The range of the alarm value is -99,999 to 999,999.

“AL-1” < > “-99999” to “999999”

PROGRAM HYSTERESIS VALUE FOR ALARM #1 (Cannot be programmed if alarm latch is programmed)

The hysteresis (*deadband*) value for alarm #1 may be programmed from 1 to 999,999. The value is either added to or subtracted from the alarm value depending on whether the alarm is high or low acting. (See *alarm section for operation.*)

“HYS-1” < > “1” to “999999”

ALARM #1 HIGH OR LOW ACTING

The action of alarm #1 may be programmed to activate either when the signal goes above the alarm value (*high acting*) or goes below it (*low acting*).

“Act-1” < > “HI” or “LO”

AUTO OR MANUAL RESET FOR ALARM #2

The reset action of alarm #2 may be programmed to reset automatically (*unlatched*) or be programmed to require a manual reset (*latched*), through either a remote input (*Pro 4, E1-CON or optional E2-CON*) or through the front panel. Latched alarms are usually used when an operator is required to take corrective action for the alarm condition.

“LATC-2” < > “yES” or “NO”

ALARM #2 ASSIGNMENT TO INPUT SIGNAL OR TOTALIZER

Alarm #2 may be programmed to activate on either the input signal or the totalizer value. If the totalizer option is not installed, this step defaults to the input.

“ASN-2” < > “INPUt” or “totAL”

PROGRAM VALUE FOR ALARM #2

The range of the alarm value is -99,999 to 999,999.

“AL-2” < > “-99999” to “999999”

PROGRAM HYSTERESIS VALUE FOR ALARM #2 (Cannot be programmed if alarm latch is programmed)

The hysteresis (*deadband*) value for alarm #2 may be programmed from 1 to 999,999. The value is either added to or subtracted from the alarm value depending on whether the alarm is high or low acting. (See *“alarms” section for operation.*)

“HYS-2” < > “1” to “999999”

ALARM #2 HIGH OR LOW ACTING

The action of alarm #2 may be programmed to activate either when the signal goes above the alarm value (*high acting*) or goes below it (*low acting*).

“Act-2” < > “HI” or “LO”

Note: Depending on options selected under Pro 3 and Pro 6, alarms, hysteresis, peak, and valley values can be monitored and/or changed when PGM.DIS. is tied to COMM. This provides a “QUICK PROGRAMMING” method for “day to day” process changes. (See QUICK PROGRAMMING SECTION for more details.)

PROGRAMMING MODULE #7 - NOT USED

PROGRAMMING MODULE #8 - PROGRAM RE-TRANSMITTED ANALOG OUTPUT

This programming module allows digital scaling of the 4 to 20 mA or 0 to 10 VDC analog output. The type of analog output is determined by the model ordered. (See Ordering Information for available models.) The display value at which 4 mA or 0 VDC and the display value at which 20 mA or 10 VDC are transmitted are keyed-in. The indicator automatically calculates slope and intercept values to complete the scaling. The analog output then follows the calculated display value and as such will update every measurement cycle. The output may also be programmed to re-transmit the contents of the totalizer instead of the input. Reverse acting output can be achieved by programming the “high” display value for the “AN-LO” programming step and the “low” display value for the “AN-HI” step.

Note: DO NOT ADJUST THE ANALOG OUTPUT POTS ON THE BACK OF THE UNIT. Fine offset and span adjustment pots are externally accessible to compensate for small drifts in the output. These pots have been set at the factory and do not normally require adjustment.

ANALOG OUTPUT SOURCE

Program whether the input signal or the totalizer will serve as the basis for the analog output signal. If the totalizer option is not installed, this step defaults to the input.

“ASIN” <> “INPUt” or “totAL”

ANALOG OUTPUT LO DISPLAY VALUE

Program the display value at which the analog output transmits 4 mA or 0 VDC.

“AN-Lo” <> “-99999” to “999999”

ANALOG OUTPUT HI DISPLAY VALUE

Program the display value at which the analog output transmits 20 mA or 10 VDC.

“AN-HI” <> “-99999” to “999999”

Programming of the re-transmitted analog output signal is complete. The indicator will return to “Pro 0”.

PROGRAMMING MODULE #9 - SERVICE OPERATIONS

CALIBRATING THE SIGNAL INPUT

The indicator has been fully calibrated at the factory and will only require a scaling operation (*Pro 1 or 2*) to display the units of the process. If the unit appears to be indicating incorrectly or inaccurately, refer to the troubleshooting section before attempting this procedure.

When re-calibration is required (*generally every 2 years*), this procedure should only be performed by qualified technicians using appropriate equipment. Signal source accuracies of 0.1% or better are required.

The procedure consists of applying accurate signal levels to the indicator in a series of three steps. Allow a 30-minute warm-up period before starting this procedure.

Note: Once the access Code (48) has been entered, there is no exiting this program module without completing the calibration procedure.

ENTER ACCESS CODE

A code number (*48*) must be keyed-in prior to the calibration sequence to guard against inadvertent entries. Access code numbers other than those listed in this section, should not be entered at this step. If any are entered, undefined or unpredictable operation could result.

“CodE” <> “0” to “99”

If the code number for the previous step was not recognized, the indicator returns to “*Pro 0*”, with no action taken. Otherwise, the calibration procedure is started.

ENTER ZERO REFERENCE

This can be accomplished by opening 5 AMP input of TBA #5. Allow the signal to stabilize for 20 seconds before pressing “P”.

“StEP 1” (Press “P”)

ENTER 50% OF RANGE

Apply 2.500 AMPS AC to input terminals. Allow signal to stabilize for 20 seconds before pressing “P”.

“StEP 2” (Press “P”)

ENTER 100% OF RANGE

Apply 5.000 AMPS AC to input terminals. Allow the signal to stabilize for 20 seconds before pressing “P”.

“StEP 3” (Press “P”)

Indicator calibration is complete. It is recommended that calibration be checked by entering “*Pro 1*” and checking the displayed input values with the signal source at different applied input levels.

RESTORING ALL PROGRAMMING PARAMETERS BACK TO FACTORY CONFIGURATION

All of the programming in Modules #1 thru #8 can be restored back to the factory configuration by entering a specific access code (*refer to the “Factory Configuration” section for the data that will be entered*). The procedure consists of entering “*Pro 9*”, keying-in “*Code 66*”, and then pressing “P”. The IMH responds by displaying “*INITIAL*” for several seconds, and then returns to “*Pro 0*”.

Note: When this procedure is performed, ALL of the scaling, presets, etc. that were programmed into the IMH will be overwritten.

“CodE” <> “66”

OPERATING THE IMH

After completing scaling and all set-up operations, the unit is ready to install and operate. After power is applied, a display test consisting of illuminating all segments for 2 seconds is performed. Afterward, the input or total will appear, depending upon the display mode prior to the last power-down. To switch the display to input, press "DOWN" (indicated by "arrows" on the front panel) and to switch to total, press "UP". A minus sign "-" will precede numbers that are negative. If a decimal point is chosen, one leading and one or more trailing zeros will accompany the decimal point.

QUICK PROGRAMMING

To limit access to the set-up parameters, connect a key-switch or wire from PGM.DIS. (TBA #3) to COMM. (TBA #5). With this pin connected to common, only a predetermined amount of data can be viewed or altered, as programmed by programming module #3. If "NO" was programmed for all of the available steps in module #3, then pressing "P" will cause the unit to display "Loc". However, if "YES" was programmed in one or more of the steps, then "P" will invoke entry into a series of commonly modified parameters while protecting the crucial set-up information. This is referred to as the "quick" programming mode. When "quick" programming mode is entered, the alarms and hysteresis values can be modified in the same manner as in the regular programming mode. The new alarm and hysteresis values will take effect when "P" is pressed. The other operations in the "quick" programming mode require special key sequences as shown:

To reset a latched alarm, scroll through steps in "quick" programming mode using the "P" button until "LAtCH1" or "LAtCH2" appears in the display. If they do not appear, they are not latched.

To reset: While "LAtCH1" or "LAtCH2" is being displayed, press and hold "DOWN" and press "P". Pressing "P" alone causes no action on the alarm.

To reset peak and valley buffers, scroll through steps in "quick" programming mode using the "P" button until "PEA" or "VAL" appears in the display.

To reset: While "PEA" or "VAL" is being displayed, press and hold "DOWN" and press "P". Pressing "P" alone causes no action on the buffer.

The front panel buttons are not only used to input data during the programming and "quick" programming mode, but control a number of other functions (if enabled in Pro "3") as well. In the normal meter mode, these functions are available:

To switch to display of input: Press "DOWN" button

To switch to display of totalizer: Press "UP" button

To re-zero input (tare): Press and hold "DOWN" and press "P"

To reset totalizer to zero: Press and hold "UP" and press "P"

To enter programming or "quick" programming: Press "P"

After each operation, a message will appear briefly to acknowledge the action.

FACTORY CONFIGURATION

The following chart lists the programming of the unit when shipped from the factory. All of the programmed parameters can be restored back to the Factory Configuration by entering a specific access code in "Pro 9". Refer to the "Programming Module #9" section for the procedure.

"Pro 1 or 2".....	"dECPNt"	-	0.00	"Pro 5".....	"dECPNt"	-	0
	"round"	-	0.01		"tbASE"	-	0 (1 second)
	"dSP 1"	-	0.00		"SCLFAC"	-	1.000
	"INP 1"	-	0.000		"Lo-cut"	-	0.00
	"dSP 2"	-	100.00	"Pro 6".....	"trAc"	-	NO
	"INP 2"	-	5.000		"dISP"	-	NO
	"SEGT"	-	1		"LAtC-1"	-	NO
"Pro 3".....	"dSP AL"	-	yES		"ASN-1"	-	input
	"ENt AL"	-	yES		"AL-1"	-	0.00
	"dSPHYS"	-	yES		"HYS-1"	-	0.01
	"ENtHYS"	-	yES		"Act-1"	-	HI
	"rSt AL"	-	yES		"LAtC-2"	-	NO
	"dSPbUF"	-	yES		"ASN-2"	-	input
	"rStbUF"	-	yES		"AL-2"	-	0.00
	"SELdSP"	-	yES		"HYS-2"	-	0.01
	"rSttOr"	-	yES		"Act-2"	-	HI
	"tArE"	-	yES	"Pro 8".....	"ASIN"	-	input
"Pro 4".....	"FILtEr"	-	1 (normal filtering)		"AN-Lo"	-	0.00
	"E1-CON"	-	4 (display hold)		"AN-HI"	-	100.00
	"E2-CON"	-	4 (display hold)				

PROGRAMMING EXAMPLE

As an example programming sequence, the IMH is employed to monitor AC current in a specific circuit of a plant. The proper current transformer ratio with a 5 amp AC output is selected.

DISPLAY: 0.00% at 0.000 amps AC and 100.00% at 5.000 amps AC. Resolution of 0.05%. Normal filtering. Latch alarm #1 if the input exceeds 90.00%, alarm must be manually reset by remote input, activate display alarms. Peak and valley (*max/min*) readings for each day to be recorded.

TOTALIZER: Integrate (*average*) the input on a per-hour basis. When the total exceeds 13,140 activate alarm #2. Disable totalization when input falls below 10.00%.

ANALOG RE-TRANSMISSION: Drive chart recorder. 4mA @ 0.00% and 20mA @ 100.00%.

“Pro 1”.....Not required since scaling done in “Pro 2”.

“Pro 2”“dECPNt” - Enter 0.00
 “round” - Enter 0.05
 “SCALE” - Enter yES
 “dSP 1” - Enter 0.00
 “INP 1” - Enter 0.000
 “dSP 2” - Enter 100.00
 “INP 2” - Enter 5.000
 “SEGt” - Enter 1

“Pro 3”.....“dSP AL” - Enter yES
 “ENt AL” - Enter yES
 “dSPHYS” - Enter NO
 “rSt AL” - Enter NO
 “dSPbUF” - Enter yES
 “rStbUF” - Enter yES

“SELdSP” - Enter yES
 “rSttOt” - Enter yES
 “tArE” - Enter NO

“Pro 4”.....“FILtEr” - Enter 1 (normal filtering)
 “E1-CON” - Enter 8 (reset latched alarm)
 “E2-CON” - Not applicable

“Pro 5”....“dECPNt” - Enter 0
 “tbASE” - Enter 2
 “SCLFAC” - Enter 0.010
 “Lo-cut” - Enter 10.00

“Pro 6”.....“trAc” - Enter NO
 “dISP” - Enter yES
 “LAtC-1” - Enter yES
 “ASN-1” - Enter input
 “AL-1” - Enter 90.00
 “HYS-1” - Not applicable
 “Act-1” - Enter HI
 “LAtC-2” - Enter NO
 “ASN-2” - Enter total
 “AL-2” - Enter 13140
 “HYS-2” - Enter 1
 “Act-2” - Enter HI


“Pro 8”.....“ASIN” - Enter input
 “AN-Lo” - Enter 0.00
 “AN-HI” - Enter 100.0

MOTOR MONITORING EXAMPLE

An IMH is employed to monitor AC current of a single-phase 10 horsepower 115V AC motor. Also, the meter will be used to total current for preventative maintenance purposes. Knowing the maximum full load current is 100 amps AC, a current transformer (CT) of 100:5 ratio is selected.

The IMH is scaled to indicate 0.00 at an input of 0.000 amps AC and 100.00 at 5.000 amps AC. Alarm #1 is programmed to activate if the motor current exceeds 84.00 amps AC, which is a 40% increase in current draw from the nominal of 60 amps AC. Alarm #1 is disabled by external control pin during motor start-up due to current surges. Peak and valley (*max/min*) reading for each day are to be recorded.

The amount of current drawn by an electric motor gives a good indication of the overall condition of the motor. Using the totalizer to total current and knowing the nominal current draw is 60 amps AC, preventative maintenance can be performed on total amp-hours. Assigned to the totalizer, Alarm #2 is programmed to latch when the predetermined amount of total amp-hours is reached (*ex. 4320 amp-hours*). Totalization is disabled if the input is below 30 amps AC.



TOTALIZER/LINEARIZER/PEAK/VALLEY/TARE (optional)

TOTALIZER

The totalizer option simply totals (*adds*) input readings together using a programmable time base and scaling coefficient. The decimal point position of the totalizer can be programmed independently of the input signal. The totalizer may be reset through a remote input or by the front panel. Alarms may be programmed to trigger from totalizer values. The programmable time bases are “*per second*”, “*per minute*” and “*per hour*”, meaning the totalizer will accumulate at a fixed rate of 2 1/2 times per second and be equal to a fixed input signal level over the selected time period. For example, if the input signal is a constant 1000 units and the “*per minute*” time base is selected, the totalizer will accumulate at the rate of 1000 units per minute. The totalizer is updated at this rate every 400 msec. As a result, the input signal is accumulated in “*batches*” of 6.6 counts every 400 msec. Therefore, the totalizer start and stop sequencing, as well as the alarm values set to trigger at specific totalizer values, are accurate only to the 400 msec totalizer update rate. The preceding example requires a scale factor of 1.000 to yield exact time bases, but any scale factor can be used to span between the ranges. (*See section on totalizer programming for detailed information.*) A programmable low signal level disable feature completes the totalizer features (*this will stop totalization when the signal level drops below this programmed value, “low cut”*). At loss of power to the indicator, the contents of the totalizer are saved. This will allow totalizing over consecutive shifts, days, etc. The total can accumulate to 999,999.

Note: The totalizer will roll over and flash when the total exceeds, 999999 or -9999, indicating an overflow condition.

TOTALIZER EXAMPLE

An IMH is employed to indicate and totalize amp-hours of an electric heater element. A current transformer with a 5 amp AC output and the proper ratio is selected (*ex. 50:5*). The input is scaled to indicate 0.00 to 50.00 amps AC. Knowing the heater element nominal current draw is 40 amps AC and the element should be serviced every 8760 amp-hours, the following programming steps are followed:

BASIC SCALING

“Pro 2”...“dECPnt”	-	0.00
“round”	-	0.01
“dSP 1”	-	0.00
“INP 1”	-	0.000
“dSP 2”	-	50.00
“INP 2”	-	5.000

TOTALIZER SET-UP

With an average signal input of 40 amps AC for the Process Display, the following formula applies:

$$S.F. = \frac{D.T.}{I.D.} \times \left(\frac{T.B.}{TIME} \right)^* \times \frac{D.T.D.P.}{I.D.D.P.}$$

S.F. = Programmable Scale Factor

D.T. = Desired Totalizer Value for a
fixed time duration

T.B. = Programmable Time Base

TB = <u>If Program Select Number Chosen Is:</u>	<u>Enter in Formula</u>
“0” for sec.	1
“1” for min.	60
“2” for hr.	3600

I.D. = Input Display Value

TIME = Actual Time period in seconds

D.T.D.P. = <u>Desired Totalizer Decimal Point</u>	<u>Enter in Formula</u>
0	1
0.0	10
0.00	100
0.000	1000
0.0000	10000

I.D.D.P. = <u>Input Display Decimal Point</u>	<u>Enter in Formula</u>
0	1
0.0	10
0.00	100
0.000	1000
0.0000	10000

$$\text{S.F.} = \frac{40}{40.00} \times \left(\frac{3600^{**}}{3600} \right)^* \times \frac{1}{100}$$

$$\text{S.F.} = 1 \times 1 \times 0.01$$

$$\text{S.F.} = 0.01$$

“Pro 5”...“dECPNt”	-	0
“tbASE”	-	2
“SCLFAC”	-	0.010
“Lo-cut”	-	0.00

The totalizer will totalize up to 999999 (999,999 Amp-Hours).


*This value is normally 1, but can be used as a coarse scale factor of 60 or 3600.

** Since the time period is in Hrs., the selected T.B. is 3600 (Program Select Value = 2) which equals per hour (3600 sec.)

LINEARIZER

The linearizer feature is a series of programmable scaling points that are used to construct linear segments to linearize the input signal. Correction for non-linearity is accomplished by continuing with scaling points beyond “DSP 2” and “INP 2” in “Pro 1” or “Pro 2”, with “DSP 3”, and “INP 3”, “DSP 4”, and “INP 4”, etc. The unit automatically calculates the linear segments between the programmed coordinates. This process of entering linear segments is also known as “curve fitting”. A maximum of nine segments are available. No restriction is placed on the ordering of the display scaling points as long as the input signal scaling points are all increasing or all decreasing. To have one or more points “back-track”, the input/output (signal/display) relationship would not be a function and would be undefined in that area. Additionally, consideration should be given to the location and length of each segment to fully minimize the segment conformity error over the desired range.

A typical curve is shown using five segments (six scaling points). Usually it is desirable to use as many segments as possible to reduce the amount of linearity error. The following program, written in GWBASIC®, calculates the number of linear slopes (segments) required to linearize a given non-linear relationship at programmable error levels.



This program calculates two sets of values. One set represents percent of full scale for the input value and the other represents percent of full scale for the display value. These values are then used by the program user to compute the actual input and display scaling points.

To use the program, copy it into any computer with GWBASIC® installed. The program uses, in subroutine 10000, the relationship between the measured parameter and the display reading. Of course, any non-linear relationship can be substituted into the subroutine to yield the % of full scale input and % of full scale display. The program will prompt for (%) of full scale error relative to display readings and any other information pertaining to the process. Increasing the conformity error decreases the number of linear slopes required to fit the function. The IMH can accommodate up to nine linear segments and it is generally desired to use all of them to minimize linearity error.

The program calculates the input/display scaling points (the location of each linear segment) as a percentage of the full scale input and full scale display. To obtain the actual input and display scaling points, multiply the respective percent of full scale values by the respective full scale range for the input and the display. “Pro 2” is then used to enter the values into the IM unit. Certain linear sections of a given curve may have a slope which exceeds the measuring resolution of the instrument. The effect will be an erratic display in that part of the curve, if not corrected. Correcting for this condition consists of three steps: increase digital filtering to level 1 or level 2, decrease display resolution to 2 or 5 and/or add dummy right hand zeros by programming 10 or 100 for “round”.

```

1 REM THIS PROGRAM WAS WRITTEN IN GWBASIC® UNDER MS-DOS 3.3
2 REM THIS PROGRAM CALCULATES THE NUMBER OF LINEAR
  SEGMENTS REQUIRED
3 REM TO CURVE-FIT A GIVEN FUNCTION, SEEN IN LINE NUMBER 10000.
4 REM LINE 10000 MAY BE MODIFIED TO ANY MATHEMATICAL
  EXPRESSION
5 REM INCLUDING THOSE WITH PROPORTIONAL CONSTANTS AND
  MULTIPLE TERMS
6 CLS
7 PRINT “ CURVE FITTING PROGRAM”
8 PRINT “”
9 DIM PA(30)

```

LINEARIZER (Cont'd)

```
40 DIM DA(30)
50 INPUT "ENTER CURVE FITTING ERROR (%)> ",E
60 P = 10000
70 GOSUB 10000
75 CR=D/P
80 ER=D*E*.01
110 CLS
111 SG=SG+1
112 PRINT "   CALCULATING LINEAR SEGMENT ";SG
115 IF P2=10000 THEN A=1:GOTO 1000
117 P2=P2+10
130 P=P1
140 GOSUB 10000
150 D1=D
170 P=P2
180 GOSUB 10000
190 D2=D
210 M=(D2-D1)/(P2-P1)
220 B=D1-(P1*M)
240 PT=P1
245 AD=(P2-P1)/6
250 PT=PT+AD
260 P=PT
270 GOSUB 10000
280 DT=D
290 DT1=(PT*M)+B
310 IF ABS(DT1-DT)>ER THEN 500
320 IF PT<P2 THEN GOTO 250
330 GOTO 115
500 P2=P2+10
510 D2=(P2*M)+B
515 P=P2
520 GOSUB 10000
550 IF ABS(D-D2)<ER THEN 500
1000 PA(SG)=P2/100
1020 DA(SG)=D2/CR/100
1200 P1=P2
```

```
1210 D1=D2
1216 IF A1 < > THEN GOTO 110
2000 CLS
2010 PRINT "NUMBER OF LINEAR SEGMENTS = ";SG
2012 PRINT "CURVE FITTING ERROR (%) = ";E
2015 PRINT ""
2016 PRINT "DISPLAY VALUES   PROCESS VALUES"
2017 PRINT "(% OF RANGE)      "; "(% OF RANGE)"
2018 PRINT ""
2019 FOR I=0 TO SG
2020 PRINT USING "###.##";DA(I);
2022 PRINT "      ";
2025 PRINT USING "###.##";PA(I)
2030 NEXT I
2040 END
10000 REM D=DISPLAY(Y), P=PROCESS(X)
10010 D= SQR(P)
10020 RETURN
```

PEAK/VALLEY

The indicator will record the lowest reading (*valley*) and the highest reading (*peak*), automatically, for later recall. This information is valuable in monitoring the limits of the process over any length of time since these values are stored at power-down to span over shifts, days, etc. An external input can be programmed to reset or engage the unit into a peak/valley reading indicator. Additionally, the peak and valley can be viewed and reset from the front panel, if so programmed.

Note: The peak/valley measurement is not instantaneous, and is based on a nominal 2 sec. response time.

TARE

The re-zero (*tare*) function can also be controlled externally or by the front panel. This feature can quickly compensate for small shifts or drifts in the input signal, by re-zeroing the input display. If the display error is greater than 10% of span due to transducer drift, it is recommended to rescale the unit with "Pro 1" or "Pro 2", rather than re-zero the input. The tare buffer can be cleared by "walking" through "Pro 2", using the "P" button.

ALARMS (Optional)

The alarm option consists of an additional printed circuit board with nine terminals. Six of these are the two Form-C relays and the other three are the two open collector transistors, which act in parallel with the relays. The two alarms are completely independent with programmable values, hysteresis (*deadband*), high or low acting, auto or manual reset, triggering from input or total, and tracking one another, if desired. If the alarms are programmed to latch (*manual reset*), then they will have to be reset either by the front panel or remote input. The alarms can be made to trigger from the totalizer instead of the input, to activate external alarms, control valves, etc. Additionally, the alarms may be programmed to activate an alarm display to alert operators of the condition.


Alarm #1 can be made to track Alarm #2 by enabling alarm tracking. This is useful in alarm set-ups where a pre-warning control activates before a second alarm shuts off the process. When tracking is programmed, changing the shut-off

trip value (*Alarm #2*) automatically changes Alarm #1 so that the offset between Alarm #2 and Alarm #1 remains the same. The following diagrams depict how the alarms work with both "HI" and "LO" acting set-ups.

Programming of the alarms can be done in the normal programming mode "Pro 6" or the unit can be programmed so that the values can only be changed in the "quick programming" mode.

If the display should indicate "OLOLOL" the alarms will deenergize, whether they are latched or unlatched.

Note: Alarm "COMM." (TBB #8) must be kept isolated from analog "-"




RE-TRANSMITTED ANALOG OUTPUT (Optional)

The re-transmitted analog output option transmits a digitally programmable 4 to 20 mA or 0 to 10 VDC signal to drive chart recorders, remote indicators and controllers. The option is contained on the upper PCB and has two outputs, "ANALOG-" (Terminal #10) and "ANALOG+" (Terminal #11) and is self-powered (active) with a compliance of 10 VDC. The analog "-" output is isolated from the signal input common, eliminating problems from ground loops. Programming of the option is performed in "Pro 8" of the normal programming mode. Display values are simply keyed in to provide a 4 mA or 0 VDC output, "AN-LO", and a 20 mA or 10 VDC output, "AN-HI". The analog output then follows the assigned value and as such will update every measurement cycle.

Nonstandard current or voltage ranges can be supported by calculating the slope and intercept of the display/output and calculating the required display values at 4 mA or 0 VDC and 20 mA or 10 VDC. Reverse action can be achieved by programming a "high" display value for "AN-LO" and a "low" display value for "AN-HI".

If the display should indicate "OLOLOL" the analog output will go to 20 mA or 10 VDC.

Note: Analog "-" must be kept isolated from alarm Common (TBB #8).



ANALOG OUTPUT CALIBRATION

Although the analog output has been calibrated at the factory, zero and span adjustments are provided to compensate for small offsets and drifts. If excessive drift is noticed, the following calibration procedure may be performed.

Scale the analog output by entering arbitrarily larger display value for "AN-HI" then for "AN-LO" in "PRO 8".


Note: Set the analog output source assignment for input.

4 to 20 mA

Exit the programming mode and apply a signal to the input of the indicator so that the display reading is below that of the value entered for "AN-LO". Adjust the zero potentiometer (*right side*) so that exactly 4.00 mA flows, as verified by an accurate ammeter. Next, apply a signal to the indicator so that the display reading is above that of the value entered for "AN-HI". (*See Appendix "B" for maximum input.*) Adjust the span potentiometer (*left side*) so that 20.00 mA is flowing. Repeat the zero and span adjustments until both are accurate. Analog output calibration is complete.

0 to 10 VDC

Exit the programming mode and apply a (temperature)/(resistance) to the input of the indicator so that the display reading is below that of the value entered for "AN-LO". Adjust the zero potentiometer (*right side*) so that exactly 0.00 VDC flows, as verified by an accurate voltmeter. Next, apply a (temperature)/(resistance) to the indicator so that the display reading is above that of the value entered for "AN-HI". (*See Appendix "B" for maximum input.*) Adjust the span potentiometer (*left side*) so that 10.00 VDC is flowing. Repeat the zero and span adjustments until both are accurate. Analog output calibration is complete.



APPENDIX "A" - INSTALLATION & CONNECTIONS

INSTALLATION ENVIRONMENT


Before installing the IM into the panel, the user should first become familiar with the unit. It may also be desirable to program the unit for the application. When programming is complete, all parameters will be saved in nonvolatile memory. The Program Disable (PGM.DIS.) terminal should be connected to COMM. to prevent accidental or unauthorized programming changes. The unit should be installed in a location that provides good air circulation. Be sure to keep it away from heat sources (ovens, furnaces, etc.), away from direct contact with

caustic vapors, oils, steam, condensation, or any other process by-products in which exposure may affect proper operation.

The bezel should be cleaned only with a soft cloth and neutral soap product. Do NOT use solvents. Continuous exposure to direct sunlight may accelerate the aging process of the bezel.


Do not use tools of any kind (screwdrivers, pens, pencils, etc.) to operate the keypad of the unit.

PANEL INSTALLATION



The unit meets NEMA 4/IP65 requirements for indoor use, when properly installed. The units are intended to be mounted into an enclosed panel with a gasket to provide a water-tight seal. Two mounting clips and screws are provided for easy installation. Consideration should be given to the thickness of the panel. A panel which is too thin may distort and not provide a water-tight seal. (Recommended minimum panel thickness is 1/8" {3.2mm}.)

After the panel cut-out has been completed and deburred, carefully slide the gasket over the rear of the unit to the back of the bezel. Insert the unit into the panel. As depicted in the drawing, install the screws into the narrow end of the mounting clips. Thread the screws into the clips until the pointed end just protrudes through the other side. Install each of the mounting clips by inserting the wide lip of the clips into the wide end of the hole, located on either side of the case. Then snap the clip onto the case. Tighten the screws evenly to apply uniform compression, thus providing a water-tight seal. **CAUTION:** Only minimum pressure is required to seal panel. Do **NOT** overtighten screws.



EMC INSTALLATION GUIDELINES

Although this unit is designed with a high degree of immunity to ElectroMagnetic Interference (EMI), proper installation and wiring methods must be followed to ensure compatibility in each application. The type of electrical noise, source or coupling method into the unit may be different for various installations. In extremely high EMI environments, additional measures may be needed. The unit becomes more immune to EMI with fewer I/O connections. Cable length, routing and shield termination are very important and can mean the difference between a successful or a troublesome installation. Listed below are some EMC guidelines for successful installation in an industrial environment.

1. The unit should be mounted in a metal enclosure, which is properly connected to protective earth.
 - a. If the bezel is exposed to high Electro-Static Discharge (ESD) levels, above 4 Kv, it should be connected to protective earth. This can be done by making sure the metal bezel makes proper contact to the panel cut-out or connecting the bezel screw with a spade terminal and wire to protective earth.
2. Use shielded (screened) cables for all Signal and Control inputs. The shield (screen) pigtail connection should be made as short as possible. The connection point for the shield depends somewhat upon the application. Listed below are the recommended methods of connecting the shield, in order of their effectiveness.
 - a. Connect the shield only at the panel where the unit is mounted to earth ground (protective earth).
 - b. Connect the shield to earth ground at both ends of the cable, usually when the noise source frequency is above 1 MHz.
 - c. Connect the shield to common of the unit and leave the other end of the shield unconnected and insulated from earth ground.
3. Never run Signal or Control cables in the same conduit or raceway with AC power lines, conductors feeding motors, solenoids, SCR controls, and heaters, etc. The cables should be run in metal conduit that is properly grounded. This is especially useful in applications where cable runs are long and portable two-way radios are used in close proximity or if the installation is near a commercial radio transmitter.
4. Signal or Control cables within an enclosure should be routed as far away as possible from contactors, control relays, transformers, and other noisy components.

5. In extremely high EMI environments, the use of external EMI suppression devices, such as ferrite suppression cores, is effective. Install them on Signal and Control cables as close to the unit as possible. Loop the cable through the core several times or use multiple cores on each cable for additional protection. Install line filters on the power input cable to the unit to suppress power line interference. Install them near the power entry point of the enclosure. The following EMI suppression devices (or equivalent) are recommended:

Ferrite Suppression Cores for signal and control cables:

Fair-Rite # 0443167251 (RLC #FCOR0000)

TDK # ZCAT3035-1330A

Steward #28B2029-0A0

Line Filters for input power cables:

Schaffner # FN610-1/07 (RLC #LFIL0000)

Schaffner # FN670-1.8/07

Corcom #1VR3

Note: Reference manufacturer's instructions when installing a line filter.

6. Long cable runs are more susceptible to EMI pickup than short cable runs. Therefore, keep cable runs as short as possible.
7. Switching of inductive loads produces high EMI. Use of snubbers across inductive loads suppresses EMI.

Snubbers:

RLC #SNUB0000


SELECT AC POWER (115/230 VAC)

The AC power to the unit must be selected for either 115 VAC or 230 VAC. The selector switch is located through an access slot on the side of the case (See Panel Installation Figure or label on case). The unit is shipped from the factory with the switch in the 230 VAC position.

Caution: Damage to the unit may occur if the AC selector switch is set incorrectly.

WIRING CONNECTIONS

After the unit has been mechanically mounted, it is ready to be wired. All wiring connections are made on removable plug-in terminal blocks. There is a separate terminal block for the bottom board (TBA) and optional top board (TBB). All conductors should meet voltage and current ratings for each terminal. Also cabling should conform to appropriate standards of good installation, local codes and regulations. It is recommended that power supplied to the unit be protected by a fuse or circuit breaker. When wiring the unit, remove the terminal block and use the numbers on the label to identify the position number with the proper function. Strip the wire, leaving approximately 1/4" bare wire exposed (*stranded wires should be tinned with solder*). Insert the wire into the terminal and tighten down the screw until the wire is clamped tightly. Each terminal can accept up to one 14-gage, two 18-gage or four 20-gage wire(s). After the terminal block is wired, install it into the proper location on the PC board. Wire each terminal block in this manner.



POWER WIRING

Primary AC power is connected to TBA #1 and 2 (*marked VAC 50/60 Hz, located on the left hand side of the bottom terminal block, as you face the rear of the meter*). To reduce the chance of noise spikes entering the AC line and affecting the indicator, the AC power should be relatively "clean" and within the specified +/-10% variation limit. Drawing power from heavily loaded circuits or circuits which also power loads that cycle on and off, (*contactors, relays, motors, machinery, etc.*) should be avoided.



CAUTION: Disconnect power to all unit terminals before removing terminal blocks. This includes deenergizing the current transformer primary circuit.

SIGNAL WIRING

AC signal wires are connected to TBA #5 and 6. If AC signal current greater than 5 amps AC is going to be applied, the appropriate size slow blow fuse should be installed.



CAUTION: The IMH is intended to be used with a 5 amp AC current transformer. Use without a current transformer will place the meter's input and output terminals at the measured circuit's potential.



CAUTION: It is recommended that the current transformer be internally protected or that a voltage clamping circuit be provided, preventing dangerous high voltage across the CT secondary windings in case of accidental opening of the secondary output leads when the primary is energized. In order to prevent risk of electric shock ensure CT is installed according to local NEC regulations for installation of current instrument transformers.

USER INPUT WIRING

User inputs (PGM.DIS., E1-CON, and optional E2-CON) are digital inputs that are active when connected to TBA #5 Common. Any form of mechanical switch, sinking collector logic with less than 0.7 V saturation may be used. The use of shielded cable is recommended. Follow the EMC Installation Guidelines for shield connection.

OUTPUT WIRING

RELAY CONNECTIONS

To prolong contact life and suppress electrical noise interference due to the switching of inductive loads, it is good installation practice to install a snubber across the contactor. Follow the manufacturer's instructions for installation.

Note: Snubber leakage current can cause some electro-mechanical devices to be held ON.

APPENDIX "B" - SPECIFICATIONS AND DIMENSIONS

- DISPLAY:** 6-digit, 0.56" (14.2 mm) High LED. Flashing display during totalizer overflow. "....." displayed during input display out of range. "OLOLOL" is displayed during input overload, which is any current greater than 5.3 amps AC.
- POWER REQUIREMENTS:**
AC Power: Switch Selectable 115/230 VAC, $\pm 10\%$, 50/60 Hz, 14 VA
- CONTROLS:** Three front panel push buttons for modifying alarm values and indicator set-up. Two external inputs for disabling the front panel and controlling programmable functions.
- INPUT RANGE:** 0.000 to 5.300 A AC @ 25 to 400 Hz.
- INPUT RESISTANCE:** 0.02Ω ; 2 W.
- MAXIMUM SHUNT CURRENT:** 50 A for 1 second;
 10 AMPS continuous.
Caution: In circuits where fault currents can exceed the maximum shunt current, a fast blow fuse should be installed in series with the input signal. Otherwise, a slow blow 10 amp fuse is recommended which will allow for start-up over current situations, while still protecting the instrument.
- ACCURACY:** (23°C, 85% R.H.)(45-500 Hz) $\pm(0.5\%$ of reading +5 digits)
- RESOLUTION:** 1 mA

9. PROGRAMMABLE DISPLAY READING RANGE:

-99999 to 999999.

10. SIGNAL CONNECTION: 2-Wire

11. READING RATE: 2.5 readings/second.

12. RESPONSE TIME: 2 seconds to settle for step input (*increases with programmable digital filtering*).

13. TOTALIZER: Front panel button for input/total display select. Programmable time-base, scale factor (0.001 to 100.000) and low-end cutout. Max. Response Time = 0.2 seconds.

14. E1-CON & E2-CON: External remote inputs that allow activation of various functions (reset total, peak indicator mode, trigger mode, etc). $V_{IL} = 0.8 V_{MAX}$; $V_{IH} = 2.0 V_{MIN}$; Max Response Time = 0.2 seconds.

15. ENVIRONMENTAL CONDITIONS:


Operating Temperature: 0° to 50°C

Storage Temperature: -40° to 80°C

Temperature Coefficient: +/- 200 ppm/°C

Operating and Storage Humidity: 85% max. relative humidity (non-condensing) from 0°C to 50°C.

Altitude: Up to 2,000 meters



16. ALARMS (Optional):

Solid State: Two, isolated, sinking open collector NPN transistors acting in parallel with relays.

$I_{\text{max}} = 100 \text{ mA}$; $V_{\text{SAT}} = 1 \text{ V @ } 100 \text{ mA}$; $V_{\text{MAX}} = 30 \text{ VDC}$.

Relays:

Type: Form C (2)

Max. Rating: 5 A 120/240 VAC or 28 VDC (*resistive load*), 1/8 HP 120 VAC (*inductive load*).

Relay Life Expectancy: 100,000 cycles at Max. Rating. (*As load level decreases, life expectancy increases.*)

17. ANALOG OUTPUT (Optional): Digital scaling and offsetting.

4 to 20 mA:

Accuracy: 0.1% of full scale

Resolution: 12 bits

Compliance Voltage: 10 VDC (*500 Ω max. loop impedance*)

0 to 10 VDC :

Accuracy: \pm (0.1% of reading +35 mV)

Resolution: 12 bits

Min. Load Resistance: 10 K Ω (*1 mA max.*)

18. LINEARIZER/PEAK/VALLEY/TARE (optional):

9-segment multiple slope scaling for non-linear inputs. Peak and Valley recording. Signal re-zero (*tare*).

19. CONSTRUCTION:

Die-cast metal front bezel that meets NEMA 4/IP65 requirements for indoor use when properly installed. Case body is black, high impact plastic (panel gasket and mounting clips included). Installation Category II, Pollution Degree 2.

20. CONNECTION:

Removable terminal blocks

21. CERTIFICATIONS AND COMPLIANCES:

SAFETY

IEC 1010-1, EN 61010-1: Safety requirements for electrical equipment for measurement, control, and laboratory use, Part 1.

IP65 Enclosure rating (Face only), IEC 529

Type 4 Enclosure rating (Face only), UL50

ELECTROMAGNETIC COMPATIBILITY

Immunity to EN 50082-2

Electrostatic discharge	EN 61000-4-2	Level 2; 4 Kv contact ¹ Level 3; 8 Kv air
Electromagnetic RF fields	EN 61000-4-3	Level 3; 10 V/m ² 80 MHz - 1 GHz
Fast transients (burst)	EN 61000-4-4	Level 4; 2 Kv I/O Level 3; 2 Kv power
RF conducted interference	EN 61000-4-6	Level 3; 10 V/rms 150 KHz - 80 MHz
Power frequency magnetic fields	EN 61000-4-8	Level 4; 30 A/m

Emissions to EN 50081-2

RF interference	EN 55011	Enclosure class A Power mains class A
-----------------	----------	--

Notes:

1. Metal bezel of unit connected with ground lead from rear bezel screw to metal mounting panel.
2. Self-recoverable loss of performance during EMI disturbance at 10 V/m: process signal deviation less than 2% of full scale. analog output signal deviation less than 8% of full scale.

For operation without loss of performance:

Unit is mounted in a metal enclosure (Buckeye SM7013-0 or equivalent)
I/O and power cables are routed in metal conduit connected to earth ground.

Refer to the EMC Installation Guidelines section of the manual for additional information.

22. WEIGHT:

1.2 lbs (0.5 kg).

APPENDIX “C” - TROUBLESHOOTING GUIDE

The majority of all problems with the indicator can be traced to improper connections or improper programming set-ups. Be sure all connections are clean and tight and check the programming set-ups for correct data. For further technical assistance, contact technical support at the numbers listed on the back cover of the instruction manual.

PROBLEM	POSSIBLE CAUSE	REMEDIES
NO DISPLAY	1. Power off, improperly connected, or brown-out.	1a. Check wiring. b. Verify power.
“PPPPPP” IN DISPLAY	1. Program data error.	1. Press “P” and Check data set-ups.
FLASHING DISPLAY	1. Totalizer overflow.	1. Reset totalizer.
“.....” IN DISPLAY	1. Input display out of range. 2. Loss of data set-ups.	1a. Check unit scaling. b. Check for electrical disturbance. 2a. Check data set-ups. b. Check for electrical disturbance. c. Disconnect and reconnect power.
DISPLAY WANDERS	1. Loss of data set-ups.	1a. Check data set-ups. b. Disconnect and reconnect power. c. Check for electrical disturbance.
JITTERY DISPLAY	1. Electrical “Noise” process or sensor lines. 2. Process inherently unstable.	1a. Increase digital filtering. b. Increase display rounding increment. c. Re-route signal wires. 2. Dampen process to eliminate oscillations.
“OLOLOL” IN DISPLAY	1. Input overload.	1. Check input levels.

APPENDIX “D” - PROGRAMMABLE FUNCTIONS

Programming of the indicator is divided into modular steps. Each module is a short sequence of data entries. The front panel buttons “UP” and “DOWN”, (shown as “arrows” on the front panel) are used to change the data and set-ups, while the “P” button is used to save or enter the data. After pressing “P” which gains entry into the programming mode, the programming modules are identified by the message “Pro” and a number in the display. “UP” and “DOWN” are used to select the desired programming module and “P” is used to enter it. All of the subsequent programming steps follow the same procedure. The rear terminal labeled “PGM. DIS.” must be ungrounded to gain access to programming. The following table lists the programming steps.

“Pro 0” - RETURN TO MEASUREMENT MODE

“Pro 1” - SCALE UNIT BY APPLYING SIGNAL

- “dECPNt” - Enter decimal point for scaled display
- “round” - Enter rounding factor and trailing zeros for scaled display
- “SCALE” - *
- “dSP 1” - Enter display reading for scaling point #1
- “INP 1” - Apply signal level for scaling point #1
- “dSP 2” - Enter display reading for scaling point #2
- “INP 2” - Apply signal level for scaling point #2
- “SEgt” - *

“Pro 2” - SCALE UNIT BY KEY-IN SIGNAL LEVEL

- “dECPNt” - Enter decimal point for scaled display
- “round” - Enter rounding factor and trailing zeros for scaled display
- “SCALE” - *
- “dSP 1” - Enter display reading for scaling point #1
- “INP 1” - Enter signal level for scaling point #1

- “dSP 2” - Enter display reading for scaling point #2
- “INP 2” - Enter signal level for scaling point #2
- “SEgt” - *

“Pro 3” - PROGRAM FUNCTIONS ACCESSIBLE WITH FRONT PANEL LOCKOUT ENGAGED

- “dSP AL” - Enable display alarms
- “ENT AL” - Enable Enter alarms **
- “dSPHYS” - Enable display hysteresis
- “ENtHYS” - Enable Enter hysteresis **
- “rSt AL” - Enable reset latched alarms
- “dSPbUF” - Enable display of peak/valley readings
- “rStbUF” - Enable reset of peak/valley readings **
- “SELdSP” - Enable switching display between input and total
- “rSttOt” - Enable reset total
- “tArE” - Enable re-zero (tare) of input signal

* - Entire sequence for this modular step is not shown (see respective programming module for further details).

** - This sequence may be subject to being locked-out due to other programmed sequences.

APPENDIX "D" - PROGRAMMABLE FUNCTIONS (Cont'd)

"Pro 4" - PROGRAM DIGITAL FILTERING AND REMOTE INPUT FUNCTION

- "FILtEr" - Enter level of digital filtering
 - 0 - no digital filtering
 - 1 - normal filtering
 - 2 - increased filtering
 - 3 - maximum filtering
- "E1-CON" - Enter function of remote switch (E1-CON)
 - 0 - re-zero input
 - 1 - reset total
 - 2 - reset and gate totalizer
 - 3 - gate totalizer
 - 4 - display hold
 - 5 - reset peak/valley
 - 6 - reset peak and start peak indicator
 - 7 - reset valley and start valley indicator
 - 8 - reset latched alarms
 - 9 - reset all alarms
 - 10 - toggle display between input and total
 - 11 - re-zero input and totalize the tared values
 - 12 - display hold with tare
 - 13 - instrument reading synchronization
- "E2-CON" - Same functions as E1-CON

"Pro 5" - PROGRAM TOTALIZER

- "dECPnt" - Enter decimal point for totalizer
- "tbASE" - Enter time base
 - 0 - second
 - 1 - minute

- 2 - hour
- "SCLFAC" - Enter multiplying scale factor
- "Lo-cut" - Enter low-signal cut out

"Pro 6" - PROGRAM ALARMS

- "trAc" - Enable alarm value tracking
- "dISP" - Enable display alarm annunciators
- "LAtC-1" - Enable alarm #1 latching
- "ASN-1" - Enter alarm #1 trigger source (input or total)
- "AL-1" - Enter alarm #1 value
- "HYS-1" - Enter hysteresis value for alarm #1
- "Act-1" - Enter alarm #1 action (high or low)
- "LAtC-2" - Enable alarm #2 latching
- "ASN-2" - Enter alarm #2 trigger source (input or total)
- "AL-2" - Enter alarm #2 value
- "HYS-2" - Enter hysteresis value for alarm #2
- "Act-2" - Enter alarm #2 action (high or low)

"Pro 7" - NOT USED

"Pro 8" - PROGRAM RE-TRANSMITTED ANALOG OUTPUT

- "ASIN" - Select source of analog output (input or total)
- "AN-Lo" - Enter 4 mA or 0 VDC display value
- "AN-HI" - Enter 20 mA or 10 VDC display value

"Pro 9" - SERVICE OPERATION

(Protected by access codes)

- "Code 48" - Basic input calibration
- "Code 66" - Reset programming to factory configuration

APPENDIX "E" - ORDERING INFORMATION

MODEL NO.	DESCRIPTION	TOTALIZER/ LINEARIZER/ PEAK/VALLEY TARE/E2-CON	DUAL ALARM OUTPUT	ANALOG OUTPUT	PART NUMBERS
					115/230 VAC
IMH	5 AMP AC Intelligent Current Meter	NO	NO	NO	IMH40060
		NO	YES	NO	IMH40062
		YES	NO	NO	IMH43060
		YES	YES	NO	IMH43062
		YES	YES	4 to 20 mA	IMH43066
		YES	YES	0 to 10 VDC	IMH43068
For information on Pricing, Enclosures, and Panel Mount Kits, refer to the RLC Catalog or contact your local RLC distributor.					

LIMITED WARRANTY

The Company warrants the products it manufactures against defects in materials and workmanship for a period limited to two years from the date of shipment, provided the products have been stored, handled, installed, and used under proper conditions. The Company's liability under this limited warranty shall extend only to the repair or replacement of a defective product, at The Company's option. The Company disclaims all liability for any affirmation, promise or representation with respect to the products.

The customer agrees to hold Red Lion Controls harmless from, defend, and indemnify RLC against damages, claims, and expenses arising out of subsequent sales of RLC products or products containing components manufactured by RLC and based upon personal injuries, deaths, property damage, lost profits, and other matters which Buyer, its employees, or sub-contractors are or may be to any extent liable, including without limitation penalties imposed by the Consumer Product Safety Act (P.L. 92-573) and liability imposed upon any person pursuant to the Magnuson-Moss Warranty Act (P.L. 93-637), as now in effect or as amended hereafter.

No warranties expressed or implied are created with respect to The Company's products except those expressly contained herein. The Customer acknowledges the disclaimers and limitations contained and relies on no other warranties or affirmations.

Red Lion Controls
20 Willow Springs Circle
York PA 17406
Tel +1 (717) 767-6511
Fax +1 (717) 764-0839

Red Lion Controls BV
Basicweg 11b
NL - 3821 BR Amersfoort
Tel +31 (0) 334 723 225
Fax +31 (0) 334 893 793

Red Lion Controls AP
31, Kaki Bukit Road 3,
#06-04/05 TechLink
Singapore 417818
Tel +65 6744-6613
Fax +65 6743-3360